# **SERVICE & OPERATING MANUAL**

**ORIGINAL INSTRUCTIONS** 




## 3" Elima-Matic Bolted Metal

with Metal Center Section

### **E3 Metal Pumps**

- Stainless Steel
- Alloy C

**EHI <b>(E) C €** 





## **Safety Information**

### **A** IMPORTANT



Read the safety warnings and instructions in this manual before pump installation and start-up. Failure to comply with the recommendations stated in this manual could damage the pump and void factory warranty.



When the pump is used for materials that tend to settle out or solidify, the pump should be flushed after each use to prevent damage. In freezing temperatures the pump should be completely drained between uses.

### **A** CAUTION



Before pump operation, inspect all fasteners for loosening caused by gasket creep. Retighten loose fasteners to prevent leakage. Follow recommended torques stated in this manual.



Plastic pumps and plastic components are not UV stabilized. Ultraviolet radiation can damage these parts and negatively affect material properties. Do not expose to UV light for extended periods of time.



#### **WARNING**

Pump not designed, tested or certified to be powered by compressed natural gas. Powering the pump with natural gas will void the warranty.



#### WARNING

The use of non-OEM replacement parts will void (or negate) agency certifications, including CE, ATEX, CSA, 3A and EC1935 compliance (Food Contact Materials). Warren Rupp, Inc. cannot ensure nor warrant non-OEM parts to meet the stringent requirements of the certifying agencies.

### WARNING



When used for toxic or aggressive fluids, the pump should always be flushed clean prior to disassembly.



Before maintenance or repair, shut off the compressed air line, bleed the pressure, and disconnect the air line from the pump. Be certain that approved eye protection and protective clothing are worn at all times. Failure to follow these recommendations may result in serious injury or death.



Airborne particles and loud noise hazards. Wear eye and ear protection.



In the event of diaphragm rupture, pumped material may enter the air end of the pump, and be discharged into the atmosphere. If pumping a product that is hazardous or toxic, the air exhaust must be piped to an appropriate area for safe containment.



Take action to prevent static sparking. Fire or explosion can result, especially when handling flammable liquids. The pump, piping, valves, containers and other miscellaneous equipment must be properly grounded.



This pump is pressurized internally with air pressure during operation. Make certain that all fasteners and piping connections are in good condition and are reinstalled properly during reassembly.



Use safe practices when lifting

## **ATEX Pumps - Conditions For Safe Use**

- 1. Ambient temperature range is as specified in tables 1 & 2 on the next page
- 2. ATEX compliant pumps are suitable for use in explosive atmospheres when the equipment is properly grounded in accordance with local electrical codes
- 3. Conductive Polypropylene, conductive Acetal or conductive PVDF pumps are not to be installed in applications where the pumps may be subjected to oil, greases and hydraulic liquids.
- 4. When operating pumps equipped with non-conductive diaphragms that exceed the maximum permissible projected area, as defined in EN ISO 80079-36: 2016 section 6.7.5 table 8, the following protection methods must be applied
  - Equipment is always used to transfer electrically conductive fluids or
  - Explosive environment is prevented from entering the internal portions of the pump, i.e. dry running.

## **Temperature Tables**

**Table 1. Category 2 ATEX Rated Pumps** 

Ambient Temperature	Process Temperature	Temperature	Maximum Surface
Range [°C]	Range [°C]	Class	Temperature [°C]
	-40°C to +80°C	T5	T100°C
	-40°C to +108°C	T4	T135°C
-20°C to +60°C	-40°C to + 160°C	Т3	
	-40°C to +177°C	(225°C) T2	T200°C

Table 2. Category M2 ATEX Rated Pumps for Mining

Ambient Temperature	Process Temperature
Range [°C]	Range [°C]
-20°C to +60°C	-40°C to +150°C

<u>Note:</u> The ambient temperature range and the process temperature range should not exceed the operating temperature range of the applied plastic parts as listed in the manuals of the pumps.

## **Table of Contents**

## SECTION 1: PUMP SPECIFICATIONS......1

- Nomenclature
- Performance
- Materials
- Dimensional Drawings

### **SECTION 2: INSTALLATION & OPERATION .10**

- Principle of Pump Operation
- Typical Installation Guide
- Troubleshooting

### SECTION 3: EXPLODED VIEW.....13


- Composite Drawings
- Parts List
- Composite Drawings
- Parts List
- Materials Code

### **SECTION 4: WARRANTY & CERTIFICATES ..18**

- Warranty
- EU Declaration of Conformity Machinery Directive
- EU Declaration of Conformity ATEX Directive

## **Explanation of Pump Nomenclature**

Your Serial #: (fill in from pump nameplate)



Model	Pump Size	Wetted Parts	Non-Wetted Parts	Diaphragm Material
E Elima-Matic	<b>6</b> 1/4"	<b>A</b> Aluminum	<b>A</b> Aluminum	1 Neoprene
<b>U</b> Ultra-Matic	<b>8</b> 3/8"	C Cast Iron	S Stainless Steel	2 Nitrile (Nitrile)
V V-Series	<b>5</b> 1/2"	S Stainless Steel	P Polypropylene	3 FKM (Fluorocarbon)
	7 3/4"	<b>H</b> Alloy C	<b>G</b> Groundable Acetal	4 EPDM
	<b>1</b> 1"	P Polypropylene	Z PTFE-coated Aluminum	<b>5</b> PTFE
	<b>4</b> 1-1/4" or 1-1/2"	<b>K</b> Kynar	J Nickel-plated Aluminum	6 Santoprene XL
	<b>2</b> 2"	<b>G</b> Groundable Acetal	C Cast Iron	7 Hytrel
	<b>3</b> 3"	B Aluminum (screen mount)	Q Epoxy-Coated Aluminum	Y FDA Santoprene

Diaphragm	Series
R Rugged	

**D** Dome X Thermo-Matic T Tef-Matic (2-piece) B Versa-Tuff (1-piece)

F FUSION (one-piece integrated plate)

1 Neoprene 2 Nitrile 3 (FKM) Fluorocarbon 4 EPDM 5 PTFE 6 Santoprene XL 7 Hytrel 8 Polyurethane A Acetal S Stainless Steel Y FDA Santoprene

## Valve Ball Material Valve Seat/Valve Seat O-Ring Material

1 Neoprene 2 Nitrile 3 (FKM) Fluorocarbon 4 EPDM **5** PTFE 6 Santoprene XL 7 Hytrel 8 Polyurethane A Aluminum w/ PTFE O-Rings S Stainless Steel w/ PTFE O-Rings

C Carbon Steel w/ PTFE O-Rings **H** Alloy C w/ PTFE O-Rings T PTFE Encapsulated Silicone O-Rings Y FDA Santoprene

**Construction Design** 

9 Bolted 0 Clamped

**Design Level** Α

C

**Miscellaneous Options B** BSP Tapered Thread **CP** Center Port **ATEX** ATEX Compliant FP Food Processing **SP** Sanitary Pump **HP** High Pressure **OE** Original Elima-Matic F Flap Valve **HD** Horizontal Discharge **3A** 3-A Certified **UL** UL Listed

**OB** Oil Bottle

More than one option may be specified for a particular pump model.



## **Materials**

Material Profile:		Operating Temperatures:	
CAUTION! Operating temperature limitations are as follows:	Max.	Min.	
Conductive Acetal: Tough, impact resistant, ductile. Good abrasion resistance and low friction surface. Generally inert, with good chemical resistance except for strong acids and oxidizing agents.	190°F 88°C	-20°F -29°C	
<b>EPDM:</b> Shows very good water and chemical resistance. Has poor resistance to oils and solvents, but is fair in ketones and alcohols.	280°F 138°C	-40°F -40°C	
<b>FKM:</b> (Fluorocarbon) Shows good resistance to a wide range of oils and sovents; especially all aliphatic, aromatic and halogenated hydrocarbons, acids, animal and vegetable oils. Hot water or hot aqueous solutions (over 70°F) will attack FKM.	350°F 177°C	-40°F -40°C	
Hytrel®: Good on acids, bases, amines and glycols at room temperatures only.	220°F 104°C	-20°F -29°C	
Neoprene: All purpose. Resistance to vegetable oils. Generally not affected by moderate chemicals, fats, greases and many oils and solvents. Generally attacked by strong oxidizing acids, ketones, esters and nitro hydrocarbons and chlorinated aromatic hydrocarbons.	200°F 93°C	-10°F -23°C	
Nitrile: General purpose, oil-resistant. Shows good solvent, oil, water and hydraulic fluid resistance. Should not be used with highly polar solvents like acetone and MEK, ozone, chlorinated hydrocarbons and nitro hydrocarbons.	190°F 88°C	-10°F -23°C	
<b>Nylon:</b> 6/6 High strength and toughness over a wide temperature range. Moderate to good resistance to fuels, oils and chemicals.	180°F 82°C	32°F 0°C	

<b>Polypropylene:</b> A thermoplastic polymer. Moderate tensile and flex strength. Resists stong acids and alkali. Attacked by chlorine, fuming nitric acid and other strong oxidizing agents.	180°F 82°C	32°F 0°C
<b>PVDF:</b> (Polyvinylidene Fluoride) A durable fluoroplastic with excellent chemical resistance. Excellent for UV applications. High tensile strength and impact resistance.	250°F 121°C	0°F -18°C
Santoprene®: Injection molded thermoplastic elastomer with no fabric layer. Long mechanical flex life. Excellent abrasion resistance.	275°F 135°C	-40°F -40°C
<b>UHMW PE:</b> A thermoplastic that is highly resistant to a broad range of chemicals. Exhibits outstanding abrasion and impact resistance, along with environmental stress-cracking resistance.	180°F 82°C	-35°F -37°C
<b>Urethane:</b> Shows good resistance to abrasives. Has poor resistance to most solvents and oils.	150°F 66°C	32°F 0°C
Virgin PTFE: (PFA/TFE) Chemically inert, virtually impervious. Very few chemicals are known to chemically react with PTFE; molten alkali metals, turbulent liquid or gaseous fluorine and a few fluoro-chemicals such as chlorine trifluoride or oxygen difluoride which readily liberate free fluorine at elevated temperatures.	220°F 104°C	-35°F -37°C

Maximum and Minimum Temperatures are the limits for which these materials can be operated. Temperatures coupled with pressure affect the longevity of diaphragm pump components. Maximum life should not be expected at the extreme limits of the temperature ranges.

#### Metals:

Alloy C: Equal to ASTM494 CW-12M-1 specification for nickel and nickel alloy.

**Stainless Steel:** Equal to or exceeding ASTM specification A743 CF-8M for corrosion resistant iron chromium, iron chromium nickel and nickel based alloy castings for general applications. Commonly referred to as 316 Stainless Steel in the pump industry.


For specific applications, always consult the Chemical Resistance Chart.

**Note:** This document is a high level guide. Please be aware that not all model and or material combinations are possible for all sizes. Please consult factory or your distributor for specific details.

## **Performance**

#### E3 - 3" Bolted Stainless Pump – Metal Center ELASTOMERIC AND TPE FITTED - RUGGED

Flow Rate
Adjustable to 0-273 gpm (1,033 lpm)
Port Size
Suction 3" ANSI 150 lbs Class (DIN80)
Discharge 3" ANSI 150 lbs Class (DIN80)
<b>Air Inlet</b> 1/2" NPT
3/4"NPT (Stainless Steel Centers ONLY)
Air Exhaust 1" NPT
Suction Lift
Dry
Wet31' (9.4 m)
Max Solid Size (Diameter)
Max Noise Level
Shipping Weights
Stainless 245 lbs (111.1 kg)
** Stainless Center add 50 lbs. (22.7 kg)




NOTE: Performance based on the following: elastomeric fitted pump, flooded suction, water at ambient conditions. The use of other materials and varying hydraulic conditions may result in deviations in excess of 5%.

#### E3 - 3" Bolted Stainless Pump – Metal Center ELASTOMERIC AND TPE FITTED - DOMED

Flow Rate
Adjustable to 0-252 gpm (954 lpm)
Port Size
Suction 3" ANSI 150 lbs Class (DIN80)
Discharge 3" ANSI 150 lbs Class (DIN80)
<b>Air Inlet</b>
3/4"NPT (Stainless Steel Centers ONLY)
Air Exhaust 1" NPT
Suction Lift
Dry
Wet32' (9.8 m)
Max Solid Size (Diameter)
Max Noise Level 94 dB(A)
Shipping Weights
Stainless 245 lbs (111.1 kg)


\*\* Stainless Center add . . . . . . . . . 50 lbs. (22.7 kg)



NOTE: Performance based on the following: elastomeric fitted pump, flooded suction, water at ambient conditions. The use of other materials and varying hydraulic conditions may result in deviations in excess of 5%.

## E3 - 3" Bolted Stainless Pump – Metal Center PTFE FITTED

Flow Rate
Adjustable to 0-186 gpm (704 lpm)
Port Size
Suction 3" ANSI 150 lbs Class (DIN80)
Discharge 3" ANSI 150 lbs Class (DIN80)
<b>Air Inlet</b>
3/4"NPT (Stainless Steel Centers ONLY)
Air Exhaust
Suction Lift
Dry
Wet31' (9.4 m)
Max Solid Size (Diameter)
Max Noise Level 92 dB(A)
Shipping Weights
Stainless 245 lbs (111.1 kg)
** Stainless Center add 50 lbs. (22.7 kg)




NOTE: Performance based on the following: PTFE fitted pump, flooded suction, water at ambient conditions. The use of other materials and varying hydraulic conditions may result in deviations in excess of 5%.





# **Dimensional Drawings**

## E3 Bolted Metal

Dimensions in inches (metric dimensions in brackets). Dimensional Tolerance .125" (3mm).









# **Dimensional Drawings**

### E3 Bolted Metal

### **Dimensionally Interchangeable with Versamatic Clamped Pumps**

Dimensions in inches (metric dimensions in brackets). Dimensional Tolerance .125" (3mm).






Model E3 Bolted Metal • 8

# **Dimensional Drawings**


## **E3 Bolted Metal**

## **Dimensionally Interchangeable with Wilden Clamped Pumps**

Dimensions in inches (metric dimensions in brackets). Dimensional Tolerance .125" (3mm).



## **Principle of Pump Operation**



Air-Operated Double Diaphragm (AODD) pumps are powered by compressed air or nitrogen.


The main directional (air) control valve ① distributes compressed air to an air chamber, exerting uniform pressure over the inner surface of the diaphragm ②. At the same time, the exhausting air ③ from behind the opposite diaphragm is directed through the air valve assembly(s) to an exhaust port ④.

As inner chamber pressure **(P1)** exceeds liquid chamber pressure **(P2)**, the rod **⑤** connected diaphragms shift together creating discharge on one side and suction on the opposite side. The discharged and primed liquid's directions are controlled by the check valves (ball or flap)**⑥** orientation.

The pump primes as a result of the suction stroke. The suction stroke lowers the chamber pressure **(P3)** increasing the chamber volume. This results in a pressure differential necessary for atmospheric pressure **(P4)** to push the fluid through the suction piping and across the suction side check valve and into the outer fluid chamber  $\mathfrak{T}$ .

Suction (side) stroking also initiates the reciprocating (shifting, stroking or cycling) action of the pump. The suction diaphragm's movement is mechanically pulled through its stroke. The diaphragm's inner plate makes contact with an actuator plunger aligned to shift the pilot signaling valve. Once actuated, the pilot valve sends a pressure signal to the opposite end of the main directional air valve, redirecting the compressed air to the opposite inner chamber.

#### SUBMERGED ILLUSTRATION



Pump can be submerged if the pump materials of construction are compatible with the liquid being pumped. The air exhaust must be piped above the liquid level. When the pumped product source is at a higher level than the pump (flooded suction condition), pipe the exhaust higher than the product source to prevent siphoning spills.

WWW. VERSAMATIC. COM Model E3 Bolted Metal • 10

## **Recommended Installation Guide**

#### **Available Accessories:** 1. Surge Suppressor Unregulated Air Supply to Surge 2. Filter/Regulator Suppressor (1) Surge Suppressor Pressure Gauge **Note**: Surge Suppressor and Piping, including air line, Shut-Off Valve must be supported after Pipe Connection (Style Optional) the flexible connections. Discharge Flexible Connector Check Valve Shut Off Drain Po Muffler Valve (Optional Piped Exhaust) Air Inlet Flexible Connector Compound (2) Filter Regulator Gauge Flexible Connection (3) Dryer Suction (4) Lubricator **CAUTION** Shut-Off Valve The air exhaust should Pipe Connection be piped to an area (Style Optional) **Drain Port** for safe disposition of the product being pumped, in the event of a diaphragm failure.

#### Installation And Start-Up

3. Air Dryer 4. Lubricator

Locate the pump as close to the product being pumped as possible. Keep the suction line length and number of fittings to a minimum. Do not reduce the suction line diameter.

#### Air Supply

Connect the pump air inlet to an air supply with sufficient capacity and pressure to achieve desired performance. A pressure regulating valve should be installed to insure air supply pressure does not exceed recommended limits.

#### Air Valve Lubrication

The air distribution system is designed to operate WITHOUT lubrication. This is the standard mode of operation. If lubrication is designed, install an air line lubricator set to deliver one drop of SAE 10 non-detergent oil for every 20 SCFM (9.4 liters/sec.) of air the pump consumes. Consult the Performance Curve to determine air consumption.

#### Air Line Moisture

Water in the compressed air supply may cause icing or freezing of the exhaust air, causing the pump to cycle erratically or stop operating. Water in the air supply can be reduced by using a point-of-use air dryer.

### Air Inlet And Priming

To start the pump, slightly open the air shut-off valve. After the pump primes, the air valve can be opened to increase air flow as desired. If opening the valve increases cycling rate, but does not increase the rate of flow, cavitation has occurred. The valve should be closed slightly to obtain the most efficient air flow to pump flow ratio.

# **Troubleshooting Guide**


Symptom:	Potential Cause(s):	Recommendation(s):
Pump Cycles Once	Deadhead (system pressure meets or exceeds air supply pressure).	Increase the inlet air pressure to the pump. Pump is designed for 1:1 pressure ratio at zero flow. (Does not apply to high pressure 2:1 units).
	Air valve or intermediate gaskets installed incorrectly.	Install gaskets with holes properly aligned.
	Bent or missing actuator plunger.	Remove pilot valve and inspect actuator plungers.
Pump Will Not Operate	Pump is over lubricated.	Set lubricator on lowest possible setting or remove. Units are designed for lube free operation.
/ Cycle	Lack of air (line size, PSI, CFM).	Check the air line size and length, compressor capacity (HP vs. cfm required).
/ Oyolc	Check air distribution system.	Disassemble and inspect main air distribution valve, pilot valve and pilot valve actuators.
	Discharge line is blocked or clogged manifolds.	Check for inadvertently closed discharge line valves. Clean discharge manifolds/piping.
	Deadhead (system pressure meets or exceeds air supply pressure).	Increase the inlet air pressure to the pump. Pump is designed for 1:1 pressure ratio at zero flow. (Does not apply to high pressure 2:1 units).
	Blocked air exhaust muffler.	Remove muffler screen, clean or de-ice, and re-install.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
	Pump chamber is blocked.	Disassemble and inspect wetted chambers. Remove or flush any obstructions.
Pump Cycles and Will	Cavitation on suction side.	Check suction condition (move pump closer to product).
Not Prime or No Flow	Check valve obstructed. Valve ball(s) not seating properly or sticking.	Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket. Clean out around valve ball cage and valve seat area. Replace valve ball or valve seat if damaged. Use heavier valve ball material.
	Valve ball(s) missing (pushed into chamber or manifold).	Worn valve ball or valve seat. Worn fingers in valve ball cage (replace part). Check Chemical Resistance Guide for compatibility.
	Valve ball(s)/seat(s) damaged or attacked by product.	Check Chemical Resistance Guide for compatibility.
	Check valve and/or seat is worn or needs adjusting.	Inspect check valves and seats for wear and proper setting. Replace if necessary.
	Suction line is blocked.	Remove or flush obstruction. Check and clear all suction screens or strainers.
	Excessive suction lift.	For lifts exceeding 20' of liquid, filling the chambers with liquid will prime the pump in most cases.
	Suction side air leakage or air in product.	Visually inspect all suction-side gaskets and pipe connections.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
Pump Cycles Running	Over lubrication.	Set lubricator on lowest possible setting or remove. Units are designed for lube free operation.
Sluggish/Stalling,	Icing.	Remove muffler screen, de-ice, and re-install. Install a point of use air drier.
Flow Unsatisfactory	Clogged manifolds.	Clean manifolds to allow proper air flow
Tion Chaudianactory	Deadhead (system pressure meets or exceeds air supply pressure).	Increase the inlet air pressure to the pump. Pump is designed for 1:1 pressure ratio at zero flow. (Does not apply to high pressure 2:1 units).
	Cavitation on suction side.	Check suction (move pump closer to product).
	Lack of air (line size, PSI, CFM).	Check the air line size, length, compressor capacity.
	Excessive suction lift.	For lifts exceeding 20' of liquid, filling the chambers with liquid will prime the pump in most cases.
	Air supply pressure or volume exceeds system hd.	Decrease inlet air (press. and vol.) to the pump. Pump is cavitating the fluid by fast cycling.
	Undersized suction line.	Meet or exceed pump connections.
	Restrictive or undersized air line.	Install a larger air line and connection.
	Suction side air leakage or air in product.	Visually inspect all suction-side gaskets and pipe connections.
	Suction line is blocked.	Remove or flush obstruction. Check and clear all suction screens or strainers.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
	Check valve obstructed.	Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket.
	Check valve and/or seat is worn or needs adjusting.	Inspect check valves and seats for wear and proper setting. Replace if necessary.
	Entrained air or vapor lock in chamber(s).	Purge chambers through tapped chamber vent plugs. Purging the chambers of air can be dangerous.
Product Leaking	Diaphragm failure, or diaphragm plates loose.	Replace diaphragms, check for damage and ensure diaphragm plates are tight.
Through Exhaust	Diaphragm stretched around center hole or bolt holes.	Check for excessive inlet pressure or air pressure. Consult Chemical Resistance Chart for compatibility with products, cleaners, temperature limitations and lubrication.
Premature Diaphragm	Cavitation.	Enlarge pipe diameter on suction side of pump.
Failure	Excessive flooded suction pressure.	Move pump closer to product. Raise pump/place pump on top of tank to reduce inlet pressure. Install Back pressure device (Tech bulletin 41r). Add accumulation tank or pulsation dampener.
	Misapplication (chemical/physical incompatibility).	Consult Chemical Resistance Chart for compatibility with products, cleaners, temperature limitations and lubrication.
	Incorrect diaphragm plates or plates on backwards, installed incorrectly or worn.	Check Operating Manual to check for correct part and installation. Ensure outer plates have not been worn to a sharp edge.
Unbalanced Cycling	Excessive suction lift.	For lifts exceeding 20' of liquid, filling the chambers with liquid will prime the pump in most cases.
	Undersized suction line.	Meet or exceed pump connections.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
	Suction side air leakage or air in product.	Visually inspect all suction-side gaskets and pipe connections.
	Check valve obstructed.	Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket.
	Check valve and/or seat is worn or needs adjusting.	Inspect check valves and seats for wear and proper setting. Replace if necessary.
	Entrained air or vapor lock in chamber(s).	Purge chambers through tapped chamber vent plugs.

For additional troubleshooting tips contact After Sales Support at service.warrenrupp@idexcorp.com or 419-524-8388



Model E3 Bolted Metal • 12

# **Composite Repair Parts Drawing - Elastomeric and TPE Fitted**



Optional orientation:
To ease assembly of the TPE diaphragms, one of the diaphragms may be reversed.

# **Composite Repair Parts List - Elastomeric and TPE Fitted**


<u> </u>	iipos	oite Nepali Parts List		
Item #	Qty.	Description	Assembly Aluminum Part Number	Stainless Steel Part Number
		Air Side Repair Kit (Includes Items 3,5,7,9,14,16,18-22)	476.V029.000	476.V030.000
1	1	Valve Body (includes items 2-11)	031.V003.156	031.V003.110
2	1	Valve Body	095.V001.156	095.V001.110
3	1 1	Valve Body Gasket		24-202
5	6	Valve Śleeve O-ring		V005.148 .206.360
6	1	Valve Spool Assembly (Includes items 7)		V001.000
7	6	Glyde Ring Assembly	P3	4-204F
8	1	Air Valve Screen	P24-210	P34-210
9	2	End Cap Gasket	P: P24 200	24-205 CP34-200
10 11	2 13	End Cap Mounting Screws (8 included on item 1)	P34-300	SP34-300 S1001
em#	Qty.	Center Secti Description	on Assembly Aluminum Part Number	Stainless Steel Part Number
12	1	Center Block Assembly (Includes item 13 & 14)	P34-400DC ASY	SP34-400
13	2	Bearing Sleeve	P	34-404
14	2	Main Shaft O-Ring		34-403
15	2	Air Chamber	196.V008.157	196.V008.110
16 17	2 8	Air Chamber Gasket Bolt	P79-109 P24-110	360.V001.360 SP24-110
17	'	Pilot Repair Kit (Includes Items 18-22)	<u>Γ24-110</u> 476	V028.000
18	1	Pilot Sleeve Assembly (include item 19)	755.	V002.000
19	6	O-ring		.101.358
20	1 1	Retaining Ring	675	.037.080
21 22	8	Pilot Spool Assembly (Includes item 22) O-ring		V006.000 .023.358
23	1	Muffler	530	.033.000
	'	Diaphragm Asser	mbly / Elastomers	.000.000
em #	Qty.	Description	Part	Number
24	1	Main Shaft	Versa-Rugged	Versa-Dome 34-103
25	2	Diaphragm (See Below Material Chart)	V305xx	V306xx
26	2	Outer Diaphragm Plate	SV302B, HV302B	SVB307 , HVB307
27	2	Inner Diaphragm Plate	V302CDC	V307B
28	12	Bolt	V302G	N/A
29 30	12	Washer Bumper Washer	V302GA	N/A 34-501
31	2	Back-Up Washer		/302E
32	4	Valve Seat (See Below Material Chart)		456xx
33	4	Valve seat O-Ring (See Note 1)	SV4	56TES-1
34	4	Valve seat O-Ring (See Note 1)	SV4	56TES-2
35	4	Valve Ball (See Below Material Chart)	Assembly	455xx
"			Assembly	Number
em#	Qty.	Description	Stainless Steel	Hastaloy
36	2	Water Chamber	SV350FB	HV350FB
37 38	36 36	Bolt Nut		V387A V387C
30	30	Nut		
39	36 I	Washer	S	V387B
39	36 2	Washer Discharge Manifold	SV351FB	V387B HV351FB
39 40	36	Discharge Manifold Discharge Drop in Manifold	SV351FB 518.V002.110	V387B HV351FB
39	36 2	Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold (BSP)	SV351FB 518.V002.110 518.V002.110 E	HV351FB
39	36 2 1 1	Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold (BSP) Suction Manifold	SV351FB 518.V002.110 518.V002.110 E SV352FFB	V387B HV351FB HV352FB
40	36 2	Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold (BSP) Suction Manifold Suction Drop in Manifold	SV351FB 518.V002.110 518.V002.110 E SV352FFB 518.V003.110	HV351FB
40	36 2 1 1	Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold (BSP) Suction Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold	SV351FB 518.V002.110 518.V002.110 E SV352FFB 518.V003.110 518.V003.110 E	HV351FB
40	36 2 1 1 1 1 1	Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold (BSP) Suction Manifold Suction Drop in Manifold Suction Drop in Manifold Suction WD Drop in Manifold Suction WD Drop in Manifold Suction WD Drop in Manifold	SV351FB 518.V002.110 518.V002.110 E SV352FFB 518.V003.110 518.V003.110 E 518.V003.110 W 518.V003.110 WE	HV351FB
40	36 2 1 1 1 1 1 1	Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold (BSP) Suction Manifold Suction Drop in Manifold Suction Drop in Manifold Suction WD Drop in Manifold Suction WD Drop in Manifold Suction WD Drop in Manifold (BSP) Suction WD Drop in Manifold (BSP) Elastomer Mater	\$V351FB 518.V002.110 518.V002.110 E \$V352FFB 518.V003.110 518.V003.110 E 518.V003.110 W 518.V003.110 WE	HV351FB HV352FB
39 40 41 <b>Mat</b>	36 2 1 1 1 1 1 1	Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold (BSP) Suction Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction WD Drop in Manifold (BSP)  Elastomer Mater Versa-Rugged Diaphragm P/N V305N	SV351FB 518.V002.110 518.V002.110 E SV352FFB 518.V003.110 518.V003.110 E 518.V003.110 W 518.V003.110 WE al Specifications Versa-Dome Diaphragm P/N V306N	HV351FB
39 40 41 <b>Mat</b> Neop Nit	36 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold (BSP) Suction Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction WD Drop in Manifold (BSP)  Elastomer Mater Versa-Rugged Diaphragm P/N V305N V305N	SV351FB 518.V002.110 518.V002.110 E SV352FFB 518.V003.110 518.V003.110 E 518.V003.110 W 518.V003.110 WE al Specifications Versa-Dome Diaphragm P/N V306N V306BN	HV351FB  HV352FB  "Ball P/N" Seat P/N  V455N V456N  V456N
40 41 Mat Neop	36 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold (BSP) Suction Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold (BSP) Suction WD Drop in Manifold Suction WD Drop in Manifold Suction WD Drop in Manifold (BSP)  Elastomer Mater Versa-Rugged Diaphragm P/N V305N V305BN V305VT	SV351FB 518.V002.110 518.V002.110 E SV352FFB 518.V003.110 518.V003.110 E 518.V003.110 W 518.V003.110 W 518.V003.110 W V306N V306N V306N V306N V306VT	HV351FB  HV352FB  "Ball P/N" Seat P/N  V455N V456N  V456N  V456BN  V456VT V456VT
40 41 Mat Neor Nitt EP	36 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold (BSP) Suction Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold (BSP) Suction WD Drop in Manifold Suction WD Drop in Manifold Suction WD Drop in Manifold (BSP)  Elastomer Mater Versa-Rugged Diaphragm P/N V305N V305N V305ND	SV351FB 518.V002.110 518.V002.110 E SV352FFB 518.V003.110 518.V003.110 E 518.V003.110 W 518.V003.110 W 518.V003.110 WE al Specifications Versa-Dome Diaphragm P/N V306N V306ND	"Ball P/N" Seat P/N V455N V456N V455BN V456BN V455VT V456VT V455ND V456ND
39 40 41 Mat Neop Nitt FF EP PT	36 2 1 1 1 1 1 1 1 1 1 cerial brene trile KM DM FE	Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold (BSP) Suction Manifold Suction Drop in Manifold Suction Drop in Manifold Suction WD Drop in Manifold Suction WD Drop in Manifold Suction WD Drop in Manifold (BSP) Elastomer Mater Versa-Rugged Diaphragm P/N V305N V305N V305ND N/A	SV351FB 518.V002.110 518.V002.110 E SV352FFB 518.V003.110 518.V003.110 E 518.V003.110 W 518.V003.110 W 518.V003.110 W  S18.V003.110 W  V306N V306N V306ND N/A	#W351FB  HV352FB  Ball P/N" Seat P/N  V455N V456N  V455BN V456BN  V455VT V456VT  V455ND V456ND  V455TF V456TF
40 41 Mat Neop Niff EP PT Santo	36 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold (BSP) Suction Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold (BSP) Suction WD Drop in Manifold Suction WD Drop in Manifold Suction WD Drop in Manifold (BSP)  Elastomer Mater Versa-Rugged Diaphragm P/N V305N V305N V305ND	SV351FB 518.V002.110 518.V002.110 E SV352FFB 518.V003.110 518.V003.110 E 518.V003.110 W 518.V003.110 W 518.V003.110 W 518.V003.110 W V306N V306N V306N V306ND N/A N/A	"Ball P/N" Seat P/N V455N V456N V455BN V456BN V455VT V456VT V455ND V456ND

#### Notes

1.) These O-Rings are only needed with the stainless steel valve seat SV456



# **Composite Repair Parts Drawing - PTFE Fitted**



# **Composite Repair Parts List - PTFE Fitted**

			Air Valve Assembly	
Item #	Qty.	Description	Aluminum Part Number	Stainless Steel Part Number
		Air Side Repair Kit (Includes Items	476.V029.000	476.V030.000
	4	3,5,7,9,14,16,18-22)		
1	1	Valve Body (includes items 2-11)	031.V003.156	031.V003.110
2	1	Valve Body	095.V001.156	095.V001.110
3	1	Valve Body Gasket	P24-	
4	1	Valve Sleeve	755.V0	
5 6	6	O-ring Valve Spool Assembly (Includes items 7)	560.20 775.V0	
7	6		P34-:	
8	1	Glyde Ring Assembly Air Valve Screen	P24-210	P34-210
9	2	End Cap Gasket	P24-210	
10	2	End Cap Gasket	P34-300	SP34-300
11	13	Mounting Screws (8 included on item 1)	S10	
	13		Center Section Assembly	JO 1
Item #	Qty.	Description	Aluminum Part Number	Stainless Steel Part Number
12	1	Center Block Assembly (Includes item 13)	P34-400DC ASY	SP34-400
13	2	Bearing Sleeve	P34-	
14	2	Main Shaft O-Ring	P34-	
15	2	Air Chamber	196.V008.157	196.V008.110
16	2	Air Chamber Gasket	P79-109	360.V001.360
17	8	Bolt	P24-110	SP24-110
		Pilot Repair Kit (Includes Items 18-22	476.V0	28.000
18	1	Pilot Sleeve Assembly (include item 19)	755.V0	
19	6	O-ring	560.10	
20	1	Retaining Ring	675.03	37.080
21	1	Pilot Spool Assembly (Includes item 22)	775.V0	
22	8	O-ring	560.02	
23	1	Muffler	530.033.000	
			ragm Assembly / Elastomers	
	Otv	Diaph	nragm Assembly / Elastomers Part N	umber
Item #	Qty.	Diaph Description	ragm Assembly / Elastomers Part N PTFE Two Piece	umber PTFE Fusion
Item #	1	Diaph Description Main Shaft	ragm Assembly / Elastomers Part N PTFE Two Piece P34-103	umber PTFE Fusion P34-103F
1tem # 24 25	1 2	Diaph Description Main Shaft Diaphragm	Part N PTFE Two Piece P34-103 V305TF-FB	umber PTFE Fusion P34-103F V305F
24 25 26	1 2 2	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm	Part N PTFE Two Piece P34-103 V305TF-FB V305TFB	umber PTFE Fusion P34-103F
24 25 26 27	1 2 2 2	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate	Part N PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO	umber PTFE Fusion P34-103F V305F
24 25 26 27 28	1 2 2 2 2	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate	Part N PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI	umber PTFE Fusion P34-103F V305F N/A
24 25 26 27 28 29	1 2 2 2 2 2 2	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer	Part N PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI P34-	umber PTFE Fusion P34-103F V305F N/A
24 25 26 27 28 29	1 2 2 2 2 2 2 2	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer	Part N PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI P34- V302E	PTFE Fusion P34-103F V305F N/A
24 25 26 27 28 29 30 31	1 2 2 2 2 2 2 2 2 4	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)	Part N   Part N	PTFE Fusion P34-103F V305F N/A  501 ee Note 1)
24 25 26 27 28 29 30 31 32	1 2 2 2 2 2 2 2 2 4 4	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)	Part N   Part N	PTFE Fusion P34-103F V305F N/A -501 ee Note 1) TES-1
24 25 26 27 28 29 30 31 32 33	1 2 2 2 2 2 2 2 2 4 4 4	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve seat O-Ring (See Note 2)	Part N   Part N	### PTFE Fusion    P34-103F
24 25 26 27 28 29 30 31 32	1 2 2 2 2 2 2 2 2 4 4	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)	Part N   Part N	### PTFE Fusion    P34-103F
24 25 26 27 28 29 30 31 32 33 34	1 2 2 2 2 2 2 2 2 2 4 4 4 4	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve Ball (See Below Material Chart)	Part N   Part N	### PTFE Fusion    P34-103F
24 25 26 27 28 29 30 31 32 33	1 2 2 2 2 2 2 2 2 4 4 4	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve seat O-Ring (See Note 2)	Part N   Part N	### PTFE Fusion    P34-103F
24 25 26 27 28 29 30 31 32 33 34	1 2 2 2 2 2 2 2 2 4 4 4 4	Diaph  Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Valve Ball (See Below Material Chart)  Description	Part N   Part N	### PTFE Fusion    P34-103F
24 25 26 27 28 29 30 31 32 33 34 <b>Item #</b>	1 2 2 2 2 2 2 2 4 4 4 4 4 4 4	Diaph  Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Description  Water Chamber	Part N   Part N   Part N	### PTFE Fusion    P34-103F
24 25 26 27 28 29 30 31 32 33 34 <b>Item #</b>	1 2 2 2 2 2 2 2 4 4 4 4 4 4 4 2 2 2 2 2	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve seat O-Ring (See Note 2)  Valve Ball (See Below Material Chart)  Description  Water Chamber  Bolt	Part N   P	### PTFE Fusion    P34-103F
24 25 26 27 28 29 30 31 32 33 34 <b>Item #</b> 35 36 37	1 2 2 2 2 2 2 2 4 4 4 4 4 4 4 2 2 36 36	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve seat O-Ring (See Note 2)  Valve Ball (See Below Material Chart)  Description  Water Chamber  Bolt  Nut	Part N   P	### PTFE Fusion    P34-103F
24 25 26 27 28 29 30 31 32 33 34 <b>Item #</b>	1 2 2 2 2 2 2 2 4 4 4 4 4 4 4 2 2 2 2 2	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve seat O-Ring (See Note 2)  Valve Ball (See Below Material Chart)  Description  Water Chamber  Bolt  Nut  Washer	Part N   P	### PTFE Fusion  ### P34-103F  ### V305F  ### N/A  ### N/A  ### S501  ### ee Note 1)  ### TES-1  ### TES-2  ### 5TF  ### ### ### Hastaloy  ### HV350FB  ### 87C  ### 87C  ### 87C
Item #   24   25   26   27   28   29   30   31   32   33   34     Item #   35   36   37   38	1 2 2 2 2 2 2 2 4 4 4 4 4 4 4 2 2 36 36	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve seat O-Ring (See Note 2)  Valve Ball (See Below Material Chart)  Description  Water Chamber  Bolt  Nut  Washer  Discharge Manifold	Part N   P	### PTFE Fusion    P34-103F
24 25 26 27 28 29 30 31 32 33 34 <b>Item #</b> 35 36 37	1 2 2 2 2 2 2 2 4 4 4 4 4 4 4 2 2 36 36	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve seat O-Ring (See Note 2)  Valve Ball (See Below Material Chart)  Description  Water Chamber  Bolt  Nut  Washer  Discharge Manifold  Discharge Drop in Manifold	Part N   Part N   Part N	### PTFE Fusion  ### P34-103F  ### V305F  ### N/A  ### N/A  ### S501  ### ee Note 1)  ### TES-1  ### TES-2  ### 5TF  ### ### ### Hastaloy  ### HV350FB  ### 87C  ### 87C  ### 87C
Item #   24   25   26   27   28   29   30   31   32   33   34     Item #   35   36   37   38	1 2 2 2 2 2 2 2 4 4 4 4 4 4 4 2 2 36 36	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve seat O-Ring (See Note 2)  Valve Ball (See Below Material Chart)  Description  Water Chamber  Bolt  Nut  Washer  Discharge Manifold  Discharge Drop in Manifold  Discharge Drop in Manifold(BSP)	Part N   P	### PTFE Fusion  ### P34-103F  ### V305F  ### N/A  ### Sold  ### P350F  #### P350F  ### P350F  ### P350F  ### P350F  ###
Item #   24   25   26   27   28   29   30   31   32   33   34     Item #   35   36   37   38	1 2 2 2 2 2 2 2 4 4 4 4 4 4 4 2 2 36 36	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve seat O-Ring (See Note 2)  Valve Ball (See Below Material Chart)  Description  Water Chamber  Bolt  Nut  Washer  Discharge Manifold  Discharge Drop in Manifold  Discharge Drop in Manifold  Discharge Drop in Manifold	Part N   P	### PTFE Fusion  ### P34-103F  ### V305F  ### N/A  ### N/A  ### S501  ### ee Note 1)  ### TES-1  ### TES-2  ### 5TF  ### ### ### Hastaloy  ### HV350FB  ### 87C  ### 87C  ### 87C
Item #   24   25   26   27   28   29   30   31   32   33   34	1 2 2 2 2 2 2 2 4 4 4 4 4 4 4 2 2 36 36	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve seat O-Ring (See Note 2)  Valve Ball (See Below Material Chart)  Description  Water Chamber  Bolt  Nut  Washer  Discharge Manifold  Discharge Drop in Manifold  Discharge Drop in Manifold  Suction Manifold  Suction Drop in Manifold	Part N   PTFE Two Piece   P34-103   V305TF-FB   V305TFB   SV302TO, HV302TO   SV302TI   P34-103   P34-103	### PTFE Fusion  ### P34-103F  ### V305F  ### N/A  ### Sold  ### P350F  #### P350F  ### P350F  ### P350F  ### P350F  ###
24 25 26 27 28 29 30 31 32 33 34 ltem # 35 36 37 38	1 2 2 2 2 2 2 2 4 4 4 4 4 4 4 2 2 36 36	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Back Up Diaphragm Plate  Inner Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve seat O-Ring (See Note 2)  Valve Ball (See Below Material Chart)  Description  Water Chamber  Bolt  Nut  Washer  Discharge Manifold  Discharge Drop in Manifold  Discharge Drop in Manifold  Suction Drop in Manifold  Suction Drop in Manifold  Suction Drop in Manifold  Suction Drop in Manifold	Part N   PTFE Two Piece   P34-103   V305TF-FB   V305TFB   SV302TO, HV302TO   SV302TI   P34-103   P34-103	### PTFE Fusion  ### P34-103F  ### V305F  ### N/A  ### Sold  ### P350F  #### P350F  ### P350F  ### P350F  ### P350F  ###
Item #   24   25   26   27   28   29   30   31   32   33   34	1 2 2 2 2 2 2 2 4 4 4 4 4 4 4 2 2 36 36	Diaph  Description  Main Shaft  Diaphragm  Back Up Diaphragm  Back Up Diaphragm  Outer Diaphragm Plate  Inner Diaphragm Plate  Bumper Washer  Back-Up Washer  Valve Seat (See Below Material Chart)  Valve seat O-Ring (See Note 2)  Valve seat O-Ring (See Note 2)  Valve Ball (See Below Material Chart)  Description  Water Chamber  Bolt  Nut  Washer  Discharge Manifold  Discharge Drop in Manifold  Discharge Drop in Manifold  Suction Manifold  Suction Drop in Manifold	Part N   PTFE Two Piece   P34-103   V305TF-FB   V305TFB   SV302TO, HV302TO   SV302TI   P34-103   P34-103	### PTFE Fusion  ### P34-103F  ### V305F  ### N/A  ### Sold  ### P350F  #### P350F  ### P350F  ### P350F  ### P350F  ###

#### Notes:

- 1.) (4) SV456 valve seats can be used as an alternative to the PTFE seats.
- 2.) These O-Rings are only needed with the stainless steel valve seat SV456



## Material Codes - The Last 3 Digits of Part Number

- 000.....Assembly, sub-assembly; and some purchased items
- 010.....Cast Iron
- 015.....Ductile Iron
- 020.....Ferritic Malleable Iron
- 080.....Carbon Steel, AISI B-1112
- 110.....Alloy Type 316 Stainless Steel
- 111 .....Alloy Type 316 Stainless Steel (Electro Polished)
- 112.....Alloy C
- 113.....Alloy Type 316 Stainless Steel (Hand Polished)
- 114.....303 Stainless Steel
- 115.....302/304 Stainless Steel
- 117.....440-C Stainless Steel (Martensitic)
- 120.....416 Stainless Steel (Wrought Martensitic)
- 148..... Hardcoat Anodized Aluminum
- 150.....6061-T6 Aluminum
- 152.....2024-T4 Aluminum (2023-T351)
- 155.....356-T6 Aluminum
- 156.....356-T6 Aluminum
- 157.....Die Cast Aluminum Alloy #380
- 158.....Aluminum Alloy SR-319
- 162.....Brass, Yellow, Screw Machine Stock
- 165.....Cast Bronze, 85-5-5-5
- 166.....Bronze, SAE 660
- 170.....Bronze, Bearing Type, Oil Impregnated
- 180.....Copper Alloy
- 305.....Carbon Steel, Black Epoxy Coated
- 306.....Carbon Steel, Black PTFE Coated
- 307.....Aluminum, Black Epoxy Coated
- 308.....Stainless Steel, Black PTFE Coated
- 309.....Aluminum, Black PTFE Coated
- 313.....Aluminum, White Epoxy Coated
- 330.....Zinc Plated Steel
- 332.....Aluminum, Electroless Nickel Plated
- 333.....Carbon Steel, Electroless Nickel Plated
- 335.....Galvanized Steel
- 337.....Silver Plated Steel
- 351.....Food Grade Santoprene®
- 353.....Geolast; Color: Black
- 354.....Injection Molded #203-40
  - Santoprene® Duro 40D +/-5; Color: RED
- 356....Hytrel®
- 357.....Injection Molded Polyurethane
- 358.....Urethane Rubber (Some Applications) (Compression Mold)
- 359..... Urethane Rubber
- 360.....Nitrile Rubber Color coded: RED
- 363.....FKM (Fluorocarbon)
  Color coded: YELLOW

- 364.....EPDM Rubber
  - Color coded: BLUE
- 365.....Neoprene Rubber Color coded: GREEN
- 366.....Food Grade Nitrile
- 368.....Food Grade EPDM
- 371.....Philthane (Tuftane)
- 374.....Carboxylated Nitrile
- 375.....Fluorinated Nitrile
- 378.....High Density Polypropylene
- 379.....Conductive Nitrile
- 408.....Cork and Neoprene
- 425.....Compressed Fibre
- 426.....Blue Gard
- 440.....Vegetable Fibre
- 500.....Delrin® 500
- 502.....Conductive Acetal, ESD-800
- 503.....Conductive Acetal, Glass-Filled
- 506.....Delrin® 150
- 520.....Injection Molded PVDF Natural color
- 540.....Nylon
- 542.....Nylon
- 544.....Nylon Injection Molded
- 550.....Polyethylene
- 551.....Glass Filled Polypropylene
- 552.....Unfilled Polypropylene
- 555.....Polyvinyl Chloride
- 556.....Black Vinyl
- 558.....Conductive HDPE
- 570.....Rulon II®
- 580.....Ryton®
- 600.....PTFE (virgin material)
  Tetrafluorocarbon (TFE)
- 603.....Blue Gylon®
- 604.....PTFE
- 606.....PTFE
- 607.....Envelon
- 608.....Conductive PTFE
- 610.....PTFE Encapsulated Silicon
- 611.....PTFE Encapsulated FKM
- 632.....Neoprene/Hytrel®
- 633.....FKM/PTFE
- 634.....EPDM/PTFE
- 635.....Neoprene/PTFE
- 637.....PTFE, FKM/PTFE
- 638.....PTFE, Hytrel®/PTFE
- 639.....Nitrile/TFE
- 643.....Santoprene®/EPDM
- 644.....Santoprene®/PTFE
- 656.....Santoprene® Diaphragm and Check Balls/EPDM Seats
- 661.....EPDM/Santoprene®
- 666.....FDA Nitrile Diaphragm,
  - PTFE Overlay, Balls, and Seals
- 668.....PTFE, FDA Santoprene®/PTFE

- Delrin and Hytrel are registered tradenames of E.I. DuPont.
- Nylatron is a registered tradename of Polymer Corp.
- Gylon is a registered tradename of Garlock. Inc.
- Santoprene is a registered tradename of Exxon Mobil Corp.
- Rulon II is a registered tradename of Dixion Industries Corp.
- Ryton is a registered tradename of Phillips Chemical Co.
- Valox is a registered tradename of General Electric Co.

## RECYCLING

Warren Rupp, manufacturer of Versamatic, is an ISO14001 registered company and is committed to minimizing the impact our products have on the environment. Many components of Versamatic® AODD pumps are made of recyclable materials. We encourage pump users to recycle worn out parts and pumps whenever possible, after any hazardous pumped fluids are thoroughly flushed. Pump users that recycle will gain the satisfaction to know that their discarded part(s) or pump will not end up in a landfill. The recyclability of Versamatic products is a vital part of Warren Rupp's commitment to environmental stewardship.



e3mdlCsmATEXMB-rev1219

## 5 - YEAR Limited Product Warranty

#### Quality System ISO9001 Certified • Environmental Management Systems ISO14001 Certified

Versamatic warrants to the original end-use purchaser that no product sold by Versamatic that bears a Versamatic brand shall fail under normal use and service due to a defect in material or workmanship within five years from the date of shipment from Versamatic's factory.

The use of non-OEM replacement parts will void (or negate) agency certifications, including CE, ATEX, CSA, 3A and EC1935 compliance (Food Contact Materials). Warren Rupp, Inc. cannot ensure nor warrant non-OEM parts to meet the stringent requirements of the certifying agencies.

~ See complete warranty at http://vm.salesmrc.com/pdfs/VM\_Product\_Warranty.pdf

## **DECLARATION OF CONFORMITY**

DECLARATION DE CONFORMITE • DECLARACION DE CONFORMIDAD • ERKLÄRUNG BEZÜGLICH EINHALTUNG DER VORSCHRIFTEN DICHIARAZIONE DI CONFORMITÀ • CONFORMITEITSVERKLARING • DEKLARATION OM ÖVERENSSTÄMMELSE EF-OVERENSSTEMMELSESERKLÆRING • VAATIMUSTENMUKAISUUSVAKUUTUS • SAMSVARSERKLÄRING DECLARACAO DE CONFORMIDADE

#### **MANUFACTURED BY:**

FABRIQUE PAR:
FABRICADA POR:
HERGESTELLT VON:
FABBRICATO DA:
VERVAARDIGD DOOR:
TILLVERKAD AV:
FABRIKANT:
VALMISTAJA:
PRODUSENT:

FABRICANTE:

#### **VERSAMATIC** ®

Warren Rupp, Inc. A Unit of IDEX Corporation 800 North Main Street P.O. Box 1568 Mansfield, OH 44901-1568 USA

Tel: 419-526-7296 Fax: 419-526-7289



2006/42/EC

EN809:2012

to Annex VIII

on Machinery, according

# PUMP MODEL SERIES: E SERIES, V SERIES, VT SERIES, VSMA3, SPA15, RE SERIES AND U2 SERIES

#### This product complies with the following European Community Directives:

Ce produit est conforme aux directives de la Communauté européenne suivantes:

Este producto cumple con las siguientes Directrices de la Comunidad Europea:

Dieses produkt erfüllt die folgenden Vorschriften der Europäischen Gemeinschaft:

Questo prodotto è conforme alle seguenti direttive CEE:

Dir produkt voldoet aan de volgende EG-richtlijnen:

Denna produkt överensstämmer med följande EU direktiv:

Versamatic, Inc., erklærer herved som fabrikant, at ovennævnte produkt er i overensstemmelse med bestemmelserne i Direkktive:

Tämä tuote täyttää seuraavien EC Direktiivien vaatimukstet:

Dette produkt oppfyller kravene til følgende EC Direktiver:

Este produto está de acordo com as seguintes Directivas comunitárias:

#### This product has used the following harmonized standards to verify conformance:

Ce materiel est fabriqué selon les normes harmonisées suivantes, afin d'en garantir la conformité:

Este producto cumple con las siquientes directrices de la comunidad europa:

Dieses produkt ist nach folgenden harmonisierten standards gefertigtworden, die übereinstimmung wird bestätigt:

Questo prodotto ha utilizzato i seguenti standards per verificare la conformita':

De volgende geharmoniseerde normen werden gehanteerd om de conformiteit van dit produkt te garanderen:

För denna produkt har följande harmoniserande standarder använts för att bekräfta överensstämmelse:

Harmoniserede standarder, der er benyttet:

Tässä tuotteessa on sovellettu seuraavia yhdenmukaistettuja standardeja:

Este produto utilizou os seguintes padrões harmonizados para varificar conformidade:

#### **AUTHORIZED/APPROVED BY:**

Approuve par:
Aprobado por:
Genehmigt von:
approvato da:
Goedgekeurd door:
Underskrift:
Valtuutettuna:
Bemyndiget av:
Autorizado Por:

Dave Roseberry
Director of Engineering

Authorized Representative: IDEX Pump Technologies R79 Shannon Industrial Estate, Shannon, Co. Clare Ireland Attn: Barry McMahon

/0047 PEV 00

DATE: February 27, 2017

FECHA: DATUM: DATA: DATO: PÄIVÄYS:

CE VMOR 044EM

06/14/2017 REV 08



WWW.VERSAMATIC.COM Model E3 Bolted Metal • 18

# **EU Declaration of Conformity**

### Manufacturer:

Versamatic A Unit of IDEX Corporation 800 North Main Street Mansfield, OH 44902 USA



Warren Rupp, Inc declares that Air Operated Double Diaphragm Pumps (AODD) and Surge Suppressors listed below comply with the requirements of **Directive 2014/34/EU** and all the applicable standards.

### **Applicable Standards:**

- EN ISO 80079-36: 2016
- EN ISO 80079-37: 2016
- EN60079-25: 2010
- 1. AODD Pumps and Surge Suppressors Technical File No.: 20310400 -1410/MER

**Hazardous Location Applied:** 

II 2 G Ex h IIC T5...225°C (T2) Gb II 2 D Ex h IIIC T100°C...T200°C Db

- Metal pump models with external aluminum components (E-series)
- Versa-Surge<sup>®</sup> surge suppressors (VTA-Series)
- 2. AODD Pumps Technical File No.: 20310400 -1410/MER On File With: DEKRA Certification B.V. (0344)

Meander 1051 6825 MJ Arnhem The Netherlands

Hazardous Location Applied:



I M2 Ex h Mb ⟨Ex⟩ II 2 G Ex h IIC T5...225°C (T2) Gb II 2 D Ex h IIIC T100°C...T200°C Db

- Metal pump models with no external aluminum (E-Series)
- Conductive plastic pumps (E-Series Plastic)
- See "Safety Information" page for conditions of safe use

DATE/OF REVISION/TITLE: 19 DEC 2018



Dave Roseberry Director of Engineering

