# **SERVICE & OPERATING MANUAL**

**ORIGINAL INSTRUCTIONS** 


**E3** 

# 3" Elima-Matic Bolted Aluminum - ATEX

with Metal Center Section

# E3 Metal Pumps

Aluminum





# **Safety Information**

## **A** IMPORTANT



Read the safety warnings and instructions in this manual before pump installation and start-up. Failure to comply with the recommendations stated in this manual could damage the pump and void factory warranty.



When the pump is used for materials that tend to settle out or solidify, the pump should be flushed after each use to prevent damage. In freezing temperatures the pump should be completely drained between uses.

## **A** CAUTION



Before pump operation, inspect all fasteners for loosening caused by gasket creep. Retighten loose fasteners to prevent leakage. Follow recommended torques stated in this manual.



Plastic pumps and plastic components are not UV stabilized. Ultraviolet radiation can damage these parts and negatively affect material properties. Do not expose to UV light for extended periods of time.



#### **WARNING**

Pump not designed, tested or certified to be powered by compressed natural gas. Powering the pump with natural gas will void the warranty.



#### **WARNING**

The use of non-OEM replacement parts will void (or negate) agency certifications, including CE, ATEX, CSA, 3A and EC1935 compliance (Food Contact Materials). Warren Rupp, Inc. cannot ensure nor warrant non-OEM parts to meet the stringent requirements of the certifying agencies.

## WARNING



When used for toxic or aggressive fluids, the pump should always be flushed clean prior to disassembly.



Before maintenance or repair, shut off the compressed air line, bleed the pressure, and disconnect the air line from the pump. Be certain that approved eye protection and protective clothing are worn at all times. Failure to follow these recommendations may result in serious injury or death.



Airborne particles and loud noise hazards. Wear eye and ear protection.



In the event of diaphragm rupture, pumped material may enter the air end of the pump, and be discharged into the atmosphere. If pumping a product that is hazardous or toxic, the air exhaust must be piped to an appropriate area for safe containment.



Take action to prevent static sparking. Fire or explosion can result, especially when handling flammable liquids. The pump, piping, valves, containers and other miscellaneous equipment must be properly grounded.



This pump is pressurized internally with air pressure during operation. Make certain that all fasteners and piping connections are in good condition and are reinstalled properly during reassembly.



Use safe practices when lifting

# ATEX Pumps - Conditions For Safe Use

- 1. Ambient temperature range is as specified in tables 1 & 2 on the next page
- 2. ATEX compliant pumps are suitable for use in explosive atmospheres when the equipment is properly grounded in accordance with local electrical codes
- 3. Conductive Polypropylene, conductive Acetal or conductive PVDF pumps are not to be installed in applications where the pumps may be subjected to oil, greases and hydraulic liquids.
- 4. When operating pumps equipped with non-conductive diaphragms that exceed the maximum permissible projected area, as defined in EN ISO 80079-36: 2016 section 6.7.5 table 8, the following protection methods must be applied
  - Equipment is always used to transfer electrically conductive fluids or
  - Explosive environment is prevented from entering the internal portions of the pump, i.e. dry running.



# **Temperature Tables**

**Table 1. Category 2 ATEX Rated Pumps** 

Ambient Temperature	Process Temperature	Temperature	Maximum Surface
Range [°C]	Range [°C]	Class	Temperature [°C]
	-40°C to +80°C	T5	T100°C
	-40°C to +108°C	T4	T135°C
-20°C to +60°C	-40°C to + 160°C	Т3	
	-40°C to +177°C	(225°C) T2	T200°C

Table 2. Category M2 ATEX Rated Pumps for Mining

Ambient Temperature	Process Temperature
Range [°C]	Range [°C]
-20°C to +60°C	-40°C to +150°C

<u>Note:</u> The ambient temperature range and the process temperature range should not exceed the operating temperature range of the applied plastic parts as listed in the manuals of the pumps.

# **Table of Contents**

# SECTION 1: PUMP SPECIFICATIONS......1

- Nomenclature
- Performance
- Materials
- Dimensional Drawings

## **SECTION 2: INSTALLATION & OPERATION ...9**

- Principle of Pump Operation
- Typical Installation Guide
- Troubleshooting

## SECTION 3: EXPLODED VIEW.....12


- Composite Drawings
- Parts List
- Composite Drawings
- Parts List
- Materials Code

## **SECTION 4: WARRANTY & CERTIFICATES..17**

- Warranty
- EU Declaration of Conformity Machinery Directive
- EU Declaration of Conformity ATEX Directive

# **Explanation of Pump Nomenclature**

Your Serial #: (fill in from pump nameplate)



Model	Pump Size	Wetted Parts	Non-Wetted Parts	Diaphragm Material
E Elima-Matic	6 1/4"	<b>A</b> Aluminum	<b>A</b> Aluminum	1 Neoprene
<b>U</b> Ultra-Matic	<b>8</b> 3/8"	C Cast Iron	S Stainless Steel	2 Nitrile (Nitrile)
<b>V</b> V-Series	<b>5</b> 1/2"	S Stainless Steel	P Polypropylene	3 FKM (Fluorocarbon)
	7 3/4"	<b>H</b> Alloy C	<b>G</b> Groundable Acetal	4 EPDM
	<b>1</b> 1"	P Polypropylene	Z PTFE-coated Aluminum	<b>5</b> PTFE
	<b>4</b> 1-1/4" or 1-1/2"	<b>K</b> Kynar	J Nickel-plated Aluminum	6 Santoprene XL
	<b>2</b> 2"	<b>G</b> Groundable Acetal	C Cast Iron	7 Hytrel
	<b>3</b> 3"	B Aluminum (screen mount)	Q Fpoxy-Coated Aluminum	Y FDA Santoprene

Diaphragm	Series
R Rugged	
<b>D</b> Dome	

X Thermo-Matic T Tef-Matic (2-piece)

B Versa-Tuff (1-piece)

F FUSION (one-piece integrated plate)

# 1 Neoprene

2 Nitrile 3 (FKM) Fluorocarbon

4 EPDM

5 PTFE 6 Santoprene XL

7 Hytrel 8 Polyurethane

A Acetal S Stainless Steel Y FDA Santoprene

#### Valve Ball Material Valve Seat/Valve Seat O-Ring Material

**Construction Design** 

9 Bolted

Α

C

0 Clamped

**Design Level** 

1 Neoprene 2 Nitrile

3 (FKM) Fluorocarbon

4 EPDM **5** PTFE 6 Santoprene XL

7 Hytrel 8 Polyurethane

A Aluminum w/ PTFE O-Rings S Stainless Steel w/ PTFE O-Rings C Carbon Steel w/ PTFE O-Rings **H** Alloy C w/ PTFE O-Rings

T PTFE Encapsulated Silicone O-Rings

Y FDA Santoprene

## **Miscellaneous Options**

**B** BSP Tapered Thread

**CP** Center Port **ATEX** ATEX Compliant

FP Food Processing **SP** Sanitary Pump

**HP** High Pressure **OE** Original Elima-Matic

F Flap Valve

**HD** Horizontal Discharge

**3A** 3-A Certified **UL** UL Listed **OB** Oil Bottle

than one option may be specified for a particular pump model.



# **Materials**

Material Profile:	Operating Temperatures:	
CAUTION! Operating temperature limitations are as follows:	Max.	Min.
Conductive Acetal: Tough, impact resistant, ductile. Good abrasion resistance and low friction surface. Generally inert, with good chemical resistance except for strong acids and oxidizing agents.	190°F 88°C	-20°F -29°C
<b>EPDM:</b> Shows very good water and chemical resistance. Has poor resistance to oils and solvents, but is fair in ketones and alcohols.	280°F 138°C	-40°F -40°C
<b>FKM:</b> (Fluorocarbon) Shows good resistance to a wide range of oils and sovents; especially all aliphatic, aromatic and halogenated hydrocarbons, acids, animal and vegetable oils. Hot water or hot aqueous solutions (over 70°F) will attack FKM.	350°F 177°C	-40°F -40°C
<b>Hytrel®:</b> Good on acids, bases, amines and glycols at room temperatures only.	220°F 104°C	-20°F -29°C
Neoprene: All purpose. Resistance to vegetable oils. Generally not affected by moderate chemicals, fats, greases and many oils and solvents. Generally attacked by strong oxidizing acids, ketones, esters and nitro hydrocarbons and chlorinated aromatic hydrocarbons.	200°F 93°C	-10°F -23°C
<b>Nitrile:</b> General purpose, oil-resistant. Shows good solvent, oil, water and hydraulic fluid resistance. Should not be used with highly polar solvents like acetone and MEK, ozone, chlorinated hydrocarbons and nitro hydrocarbons.	190°F 88°C	-10°F -23°C
<b>Nylon:</b> 6/6 High strength and toughness over a wide temperature range. Moderate to good resistance to fuels, oils and chemicals.	180°F 82°C	32°F 0°C

<b>Polypropylene:</b> A thermoplastic polymer. Moderate tensile and flex strength. Resists stong acids and alkali. Attacked by chlorine, fuming nitric acid and other strong oxidizing agents.	180°F 82°C	32°F 0°C
<b>PVDF:</b> (Polyvinylidene Fluoride) A durable fluoroplastic with excellent chemical resistance. Excellent for UV applications. High tensile strength and impact resistance.	250°F 121°C	0°F -18°C
<b>Santoprene®</b> : Injection molded thermoplastic elastomer with no fabric layer. Long mechanical flex life. Excellent abrasion resistance.	275°F 135°C	-40°F -40°C
<b>UHMW PE:</b> A thermoplastic that is highly resistant to a broad range of chemicals. Exhibits outstanding abrasion and impact resistance, along with environmental stress-cracking resistance.	180°F 82°C	-35°F -37°C
<b>Urethane:</b> Shows good resistance to abrasives. Has poor resistance to most solvents and oils.	150°F 66°C	32°F 0°C
Virgin PTFE: (PFA/TFE) Chemically inert, virtually impervious. Very few chemicals are known to chemically react with PTFE; molten alkali metals, turbulent liquid or gaseous fluorine and a few fluoro-chemicals such as chlorine trifluoride or oxygen difluoride which readily liberate free fluorine at elevated temperatures.	220°F 104°C	-35°F -37°C

Maximum and Minimum Temperatures are the limits for which these materials can be operated. Temperatures coupled with pressure affect the longevity of diaphragm pump components. Maximum life should not be expected at the extreme limits of the temperature ranges.

#### Metals:

Alloy C: Equal to ASTM494 CW-12M-1 specification for nickel and nickel alloy.


**Stainless Steel:** Equal to or exceeding ASTM specification A743 CF-8M for corrosion resistant iron chromium, iron chromium nickel and nickel based alloy castings for general applications. Commonly referred to as 316 Stainless Steel in the pump industry.

For specific applications, always consult the Chemical Resistance Chart.

**Note:** This document is a high level guide. Please be aware that not all model and or material combinations are possible for all sizes. Please consult factory or your distributor for specific details.

# **Performance**


# E3 3" Bolted Aluminum Rubber and TPE Fitted - Rugged



NOTE: Performance based on the following: PTFE fitted pump, flooded suction, water at ambient conditions. The use of other materials and varying hydraulic conditions may result in deviations in excess of 5%.

# E3 3" Bolted Aluminum Rubber and TPE Fitted - Domed


Flow Rate
Adjustable to 0-252 gpm (954 lpm)
Port Size
Suction 3" ANSI 150 lbs. Class (DIN80)
Discharge 3" ANSI 150 lbs. Class
<b>Air Inlet</b>
Air Exhaust 1" NPT
Suction Lift
Dry
Wet
Max Solid Size (Diameter)
3/8" (9.5 mm)
Max Noise Level
Shipping Weights
Aluminum 146 lbs. (66.2 kg)



NOTE: Performance based on the following: PTFE fitted pump, flooded suction, water at ambient conditions. The use of other materials and varying hydraulic conditions may result in deviations in excess of 5%.

# E3 3" Bolted Aluminum PTFE Fitted

Flow Rate
Adjustable to 0-186 gpm (704 lpm)
Port Size
Suction 3" ANSI 150 lbs. Class (DIN80)
Discharge 3" ANSI 150 lbs. Class
<b>Air Inlet</b>
Air Exhaust 1" NPT
Suction Lift
Dry
Wet
Max Solid Size (Diameter)
3/8" (9.5 mm)
Max Noise Level
Shipping Weights
Aluminum 146 lbs. (66.2 kg)




NOTE: Performance based on the following: PTFE fitted pump, flooded suction, water at ambient conditions. The use of other materials and varying hydraulic conditions may result in deviations in excess of 5%.




Model E3 Aluminum Bolted • 6

# **Dimensional Drawings**

# **E3 Aluminum Bolted - ANSI Flange**Dimensions in inches (metric dimensions in brackets). Dimensional Tolerance .125" (3mm).









# **Dimensional Drawings**


# E3 Aluminum Bolted - NPT / BSP

## Dimensionally Interchangeable with Versa-Matic and Wilden Clamped Pumps

Dimensions in inches (metric dimensions in brackets). Dimensional Tolerance .125" (3mm).








WWW.VERSAMATIC.COM Model E3 Aluminum Bolted • 8

# **Principle of Pump Operation**



Air-Operated Double Diaphragm (AODD) pumps are powered by compressed air or nitrogen.


The main directional (air) control valve ① distributes compressed air to an air chamber, exerting uniform pressure over the inner surface of the diaphragm ②. At the same time, the exhausting air ③ from behind the opposite diaphragm is directed through the air valve assembly(s) to an exhaust port ④.

As inner chamber pressure **(P1)** exceeds liquid chamber pressure **(P2)**, the rod **⑤** connected diaphragms shift together creating discharge on one side and suction on the opposite side. The discharged and primed liquid's directions are controlled by the check valves (ball or flap)**⑥** orientation.

The pump primes as a result of the suction stroke. The suction stroke lowers the chamber pressure **(P3)** increasing the chamber volume. This results in a pressure differential necessary for atmospheric pressure **(P4)** to push the fluid through the suction piping and across the suction side check valve and into the outer fluid chamber  $\mathfrak{T}$ .

Suction (side) stroking also initiates the reciprocating (shifting, stroking or cycling) action of the pump. The suction diaphragm's movement is mechanically pulled through its stroke. The diaphragm's inner plate makes contact with an actuator plunger aligned to shift the pilot signaling valve. Once actuated, the pilot valve sends a pressure signal to the opposite end of the main directional air valve, redirecting the compressed air to the opposite inner chamber.


#### SUBMERGED ILLUSTRATION



Pump can be submerged if the pump materials of construction are compatible with the liquid being pumped. The air exhaust must be piped above the liquid level. When the pumped product source is at a higher level than the pump (flooded suction condition), pipe the exhaust higher than the product source to prevent siphoning spills.



# **Recommended Installation Guide**



#### Installation And Start-Up

Locate the pump as close to the product being pumped as possible. Keep the suction line length and number of fittings to a minimum. Do not reduce the suction line diameter.

#### Air Supply

Connect the pump air inlet to an air supply with sufficient capacity and pressure to achieve desired performance. A pressure regulating valve should be installed to insure air supply pressure does not exceed recommended limits.

#### Air Valve Lubrication

The air distribution system is designed to operate WITHOUT lubrication. This is the standard mode of operation. If lubrication is designed, install an air line lubricator set to deliver one drop of SAE 10 non-detergent oil for every 20 SCFM (9.4 liters/sec.) of air the pump consumes. Consult the Performance Curve to determine air consumption.

#### Air Line Moisture

Water in the compressed air supply may cause icing or freezing of the exhaust air, causing the pump to cycle erratically or stop operating. Water in the air supply can be reduced by using a point-of-use air dryer.

#### **Air Inlet And Priming**

To start the pump, slightly open the air shut-off valve. After the pump primes, the air valve can be opened to increase air flow as desired. If opening the valve increases cycling rate, but does not increase the rate of flow, cavitation has occurred. The valve should be closed slightly to obtain the most efficient air flow to pump flow ratio.



# **Troubleshooting Guide**


Symptom:	Potential Cause(s):	Recommendation(s):
Pump Cycles Once	Deadhead (system pressure meets or exceeds air supply pressure).	Increase the inlet air pressure to the pump. Pump is designed for 1:1 pressure ratio at zero flow. (Does not apply to high pressure 2:1 units).
	Air valve or intermediate gaskets installed incorrectly.	Install gaskets with holes properly aligned.
	Bent or missing actuator plunger.	Remove pilot valve and inspect actuator plungers.
Pump Will Not Operate	Pump is over lubricated.	Set lubricator on lowest possible setting or remove. Units are designed for lube free operation.
/ Cycle	Lack of air (line size, PSI, CFM).	Check the air line size and length, compressor capacity (HP vs. cfm required).
	Check air distribution system.	Disassemble and inspect main air distribution valve, pilot valve and pilot valve actuators.
	Discharge line is blocked or clogged manifolds.	Check for inadvertently closed discharge line valves. Clean discharge manifolds/piping.
	Deadhead (system pressure meets or exceeds air supply pressure).	Increase the inlet air pressure to the pump. Pump is designed for 1:1 pressure ratio at zero flow. (Does not apply to high pressure 2:1 units).
	Blocked air exhaust muffler.	Remove muffler screen, clean or de-ice, and re-install.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
	Pump chamber is blocked.	Disassemble and inspect wetted chambers. Remove or flush any obstructions.
Pump Cycles and Will	Cavitation on suction side.	Check suction condition (move pump closer to product).
Not Prime or No Flow	Check valve obstructed. Valve ball(s) not seating properly or sticking.	Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket. Clean out around valve ball cage and valve seat area. Replace valve ball or valve seat if damaged. Use heavier valve ball material.
	Valve ball(s) missing (pushed into chamber or manifold).	Worn valve ball or valve seat. Worn fingers in valve ball cage (replace part). Check Chemical Resistance Guide for compatibility.
	Valve ball(s)/seat(s) damaged or attacked by product.	Check Chemical Resistance Guide for compatibility.
	Check valve and/or seat is worn or needs adjusting.	Inspect check valves and seats for wear and proper setting. Replace if necessary.
	Suction line is blocked.	Remove or flush obstruction. Check and clear all suction screens or strainers.
	Excessive suction lift.	For lifts exceeding 20' of liquid, filling the chambers with liquid will prime the pump in most cases.
	Suction side air leakage or air in product.	Visually inspect all suction-side gaskets and pipe connections.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
Pump Cycles Running	Over lubrication.	Set lubricator on lowest possible setting or remove. Units are designed for lube free operation.
Sluggish/Stalling,	Icing.	Remove muffler screen, de-ice, and re-install. Install a point of use air drier.
Flow Unsatisfactory	Clogged manifolds.	Clean manifolds to allow proper air flow
Tiow offsatisfactory	Deadhead (system pressure meets or exceeds air supply pressure).	Increase the inlet air pressure to the pump. Pump is designed for 1:1 pressure ratio at zero flow. (Does not apply to high pressure 2:1 units).
	Cavitation on suction side.	Check suction (move pump closer to product).
	Lack of air (line size, PSI, CFM).	Check the air line size, length, compressor capacity.
	Excessive suction lift.	For lifts exceeding 20' of liquid, filling the chambers with liquid will prime the pump in most cases.
	Air supply pressure or volume exceeds system hd.	Decrease inlet air (press. and vol.) to the pump. Pump is cavitating the fluid by fast cycling.
	Undersized suction line.	Meet or exceed pump connections.
	Restrictive or undersized air line.	Install a larger air line and connection.
	Suction side air leakage or air in product.	Visually inspect all suction-side gaskets and pipe connections.
	Suction line is blocked.	Remove or flush obstruction. Check and clear all suction screens or strainers.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
	Check valve obstructed.	Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket.
	Check valve and/or seat is worn or needs adjusting.	Inspect check valves and seats for wear and proper setting. Replace if necessary.
	Entrained air or vapor lock in chamber(s).	Purge chambers through tapped chamber vent plugs. Purging the chambers of air can be dangerous.
Product Leaking	Diaphragm failure, or diaphragm plates loose.	Replace diaphragms, check for damage and ensure diaphragm plates are tight.
Through Exhaust	Diaphragm stretched around center hole or bolt holes.	Check for excessive inlet pressure or air pressure. Consult Chemical Resistance Chart for compatibility with products, cleaners, temperature limitations and lubrication.
Premature Diaphragm	Cavitation.	Enlarge pipe diameter on suction side of pump.
Failure	Excessive flooded suction pressure.	Move pump closer to product. Raise pump/place pump on top of tank to reduce inlet pressure. Install Back pressure device (Tech bulletin 41r). Add accumulation tank or pulsation dampener.
	Misapplication (chemical/physical incompatibility).	Consult Chemical Resistance Chart for compatibility with products, cleaners, temperature limitations and lubrication.
	Incorrect diaphragm plates or plates on backwards, installed incorrectly or worn.	Check Operating Manual to check for correct part and installation. Ensure outer plates have not been worn to a sharp edge.
Unbalanced Cycling	Excessive suction lift.	For lifts exceeding 20' of liquid, filling the chambers with liquid will prime the pump in most cases.
, ,	Undersized suction line.	Meet or exceed pump connections.
1	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
		The state of the s
	Suction side air leakage or air in product.	Visually inspect all suction-side gaskets and pipe connections.
	Suction side air leakage or air in product.  Check valve obstructed.	Visually inspect all suction-side gaskets and pipe connections.  Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket.
	· ·	

For additional troubleshooting tips contact After Sales Support at service.warrenrupp@idexcorp.com or 419-524-8388





3: EXP VIEW


# **Composite Repair Parts Drawing - Elastomeric and TPE Fitted**



Torque Setting: 720 in-lbs. (81 N-m) 960 in-lbs (XL) (180 N-m) (XL)







Ф

Optional orientation: To ease assembly of the TPE diaphragms, one of the diaphragms may be reversed.


# **Composite Repair Parts List - Elastomeric and TPE Fitted**


	iipo	<u> </u>				
Itana #	Otre	Description	Air Valve Assembly	Dovi N		
Item #	Qty.	Air Side Repair Kit (Includes Items			umber	
		3,5,7,9,14,16,18-22)		476.02	29.000	
1	1	Valve Body (includes items 2-11)			03.156	
2	1	Valve Body			01.156	1
3	1	Valve Body Gasket			-202	
5	6	Valve Sleeve O-ring			05.148 06.360	
6	1	Valve Spool Assembly (Includes items 7)			01.000	
$\frac{1}{7}$	6	Glyde Ring Assembly			204F	
8	1	Air Valve Screen			-210	
9	2	End Cap Gasket	P24-205			
10	2	End Cap			-300	
11	13	Mounting Screws (8 included on item 1)	S1001			
Item #	Qty.	Description	enter Section Assemb		umber	
12	1 Qty.	Center Block Assembly (Includes item 13&14)		P34-400		
13	2	Bearing Sleeve			-404	
14	2	Main Shaft O-Ring			-403	
15	2	Air Chamber		196.VC		
16	2	Air Chamber Gasket		P79		
17	8	Bolt (10 do 10 do			-110	
40		Pilot Repair Kit (Includes Items 18-22)		476.0		
18 19	6	Pilot Sleeve Assembly (include item 19) O-ring		755.V0	02.000 01.358	
20	1	Retaining Ring		675.0		
21	1	Pilot Spool Assembly (Includes item 22)			06.000	
22	8	O-ring			23.358	
23	1	Muffler			33.000	
		Diaphi	agm Assembly / Elast			
Item #	Qty.	Description	Versa-F		umber	-Dome
24	1	Main Shaft	VCISA-I		-103	-Donie
25	2	Diaphragm (See Below Material Chart)	V30			06xx
26	2	Outer Diaphragm Plate	V302			307
27	2	Inner Diaphragm Plate	V302			07B
28	1 19	Bolt	V302G V307B V307B		Ι/Δ	
	12		V302GA N/A			
29	12	Washer		2GA	N	
29 30	12 2	Washer Bumper Washer		2GA P34	-501	
29 30 31	12 2 2	Washer Bumper Washer Back-Up Washer		2GA P34 V3	N -501 D2E	
29 30	12 2	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart)	V30:	2GA P34 V30 V45	-501	
29 30 31 32 33	12 2 2 4 4	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)		2GA P34 V3I V45 V45	N -501 02E 66xx 55xx	
29 30 31 32 33 Item #	12 2 2 4 4 Qty.	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description	V30:	2GA P34 V3i V45 V45	N -501 02E 66xx 55xx <b>umber</b>	
29 30 31 32 33 Item #	12 2 2 4 4 Qty.	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber	V30:	2GA P34 V31 V45 V45 <b>Part N</b>	N-501 02E 66xx 55xx <b>umber</b> 0FB	
29 30 31 32 33 <b>Item #</b> 34 35	12 2 2 4 4 4 <b>Qty.</b> 2 20	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt	V30:	P34 V30 V45 V45 Part N V35	N-501 02E 66xx 55xx <b>umber</b> 0FB 55.330	
29 30 31 32 33 Item #	12 2 2 4 4 Qty.	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut	V30:	P34 V31 V45 V45 Part N V35 170.09	N-501 02E 66xx 55xx <b>umber</b> 0FB	
29 30 31 32 33 <b>Item #</b> 34 35 36 37 38	12 2 2 4 4 4 <b>Qty.</b> 2 20 52 52 52	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt	V30:	P34 V30 V45 V45  Part N V35 170.00 V36 V35 V35 V35	N-501 D2E G6xx S5xx <b>umber</b> OFB 055.330 B7C B7B 8FB	
29 30 31 32 33 <b>Item #</b> 34 35 36 37 38 39	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 52 2	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow	V30:	P34 V30 V45 V45  Part N V35 170.00 V36 V35 V35	N-501 D2E G6xx S5xx <b>umber</b> OFB 55.330 B7C B7B 8FB 8FB	
29 30 31 32 33 <b>Item #</b> 34 35 36 37 38 39 40	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 52 2	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow	V30:	P34 V30 V45 V45  Part N V35 170.00 V36 V35 V351 V355	N-501 D2E G6xx S5xx Umber OFB 55.330 B7C B7B 8FB E-FB	
29 30 31 32 33 <b>Item #</b> 34 35 36 37 38 39 40 41	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 52 2 2	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring	V30:	P34 V3 V45 V45  Part N V35 170.09 V36 V35 V35 V351 V352 V25	N-501 02E 66xx 55xx wmber 0FB 55.330 87C 87B 8FB E-FB	
29 30 31 32 33 <b>Item #</b> 34 35 36 37 38 39 40 41 42	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 52 2	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring Elbow Bolt	V30:	P34 V3 V45 V45  Part N V35 170.09 V36 V35 V35 V351 V352 V352 V352 V354 V352 V354	N-501 D2E G6xx F5xx wmber OFB 55.330 B7C B7B 8FB E-FB E-FB	
29 30 31 32 33 <b>Item #</b> 34 35 36 37 38 39 40 41	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 52 2 2	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring Elbow Bolt Discharge Drop in Manifold	V30:	P34 V3 V45 V45  Part N V35 170.09 V36 V35 V35 V351 V352 V352 V353 V351 V352 V351	N-501 02E 66xx 55xx wmber 0FB 05.330 87C 87B 8FB E-FB E-FB 68xx 87D 02.156	
29 30 31 32 33 Item # 34 35 36 37 38 39 40 41 42 43	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 52 2 2	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold (BSP)	V30:	P34 V3 V45 V45  Part N V35 170.09 V36 V35 V35 V351 V352 V351 V352 V25 V36 518.V00	N-501 02E 66xx 55xx wmber 0FB 55.330 87C 87B 8FB E-FB E-FB 68xx 87D 02.156	
29 30 31 32 33 <b>Item #</b> 34 35 36 37 38 39 40 41 42	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 52 2 2	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold	Wet End Assembly	P34 V3 V45 V45  Part N V35 170.09 V36 V35 V35 V351 V352 V35 S18.V0 518.V0 518.V0	N-501 02E 66xx 55xx wmber 0FB 05.330 87C 87B 8FB E-FB E-FB 68xx 87D 02.156	
29 30 31 32 33 Item # 34 35 36 37 38 39 40 41 42 43	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 52 2 2	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold	Wet End Assembly	P34 V3 V45 V45  Part N V35 170.09 V36 V35 V35 V351 V352 V35 S18.V0 518.V0 518.V0	N-501 02E 66xx 65xx wmber 0FB 55.330 87C 87B 8FB E-FB E-FB 68xx 87D 02.156 12.156 E	I/A
29 30 31 32 33 Item # 34 35 36 37 38 39 40 41 42 43	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 52 2 2	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold	Wet End Assembly  Omer Material Specific  Versa-Dome	P34 V3 V45 V45  Part N V35 170.09 V36 V35 V35 V351 V352 V35 S18.V0 518.V0 518.V0	N-501 02E 66xx 65xx wmber 0FB 55.330 87C 87B 8FB E-FB E-FB 68xx 87D 02.156 12.156 E	I/A  "Manifold Tee
29 30 31 32 33 <b>Item #</b> 34 35 36 37 38 39 40 41 42 43	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 2 2 4 32 1 1 1	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold (BSP) Suction Drop in Manifold (BSP) Elasto Versa-Rugged Diaphragm P/N	Wet End Assembly  Omer Material Specific  Versa-Dome Diaphragm P/N	P34 V3 V45 V45  Part N V35 170.09 V36 V35 V35 V351 V352 V35 V351 V352 V25 V36 518.V00 518.V00 ations "Ball P/N"	N-501 02E 66xx 65xx 0FB 65.330 87C 87B 8FB E-FB 6-FB 6-FB 6-FB 6-FB 6-FB 6-FB 6-FB 6	"Manifold Tee O-ring P/N"
29 30 31 32 33 <b>Item #</b> 34 35 36 37 38 39 40 41 42 43 44	12 2 2 4 4 4 <b>Qty.</b> 2 20 52 52 2 2 4 32 1 1	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold (BSP)	Wet End Assembly  Omer Material Specific  Versa-Dome	P34 V36 V45 V45 V45 V45 V45 V45 V45 V45 V45 V36 V36 V36 V36 V35 V351 V352 V26 V38 518.V00 518.V00 ations	N-501 02E 66xx 65xx wmber 0FB 55.330 87C 87B 8FB E-FB E-FB 68xx 87D 002.156 103.156 E	"Manifold Tee O-ring P/N" N/A
29 30 31 32 33 <b>Item #</b> 34 35 36 37 38 39 40 41 42 43 44 <b>Mat</b>	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 2 2 4 32 1 1 1 1 1 terial	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold (BSP) Suction Drop in Manifold (BSP) Elasto Versa-Rugged Diaphragm P/N  V305N V305BN V305VT	Wet End Assembly  Mer Material Specific  Versa-Dome  Diaphragm P/N  V306N  V306BN  V306VT	P34 V3 V45  Part N V35 170.09 V36 V35 V35 V35 V351 V352 V25 V36 518.V00 518.V00 518.V00 64tions "Ball P/N" V455N V455BN V455VT	N-501 02E 66xx 65xx 0FB 65.330 87C 87B 8FB E-FB 8-FB 6-FB 6-FB 6-FB 6-FB 6-FB 6-FB 6-FB 6	"Manifold Tee O-ring P/N" N/A V258BN V258VT
29 30 31 32 33 <b>Item #</b> 34 35 36 37 38 39 40 41 42 43 44 <b>Mat</b> Neo Ni	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 2 2 4 32 1 1 1 1 1 terial	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold (BSP) Suction Drop in Manifold (BSP) Elasto Versa-Rugged Diaphragm P/N V305N V305N V305ND	Wet End Assembly  Mer Material Specific  Versa-Dome  Diaphragm P/N  V306N  V306BN  V306VT  V306ND	P34 V3 V45  Part N V35 170.09 V36 V35 V35 V35 V351 V352 V25 V36 518.V0 518.V0 518.V0 618.V0 618.V0 V36 V36 V37 V37 V37 V37 V37 V38	N-501 D2E B6xx B5xx  wmber OFB D5.330 B7C B7B B8FB E-FB E-FB B2.FB B2.156 D2.156 D3.156 D4.256 D5.256 D5.25	"Manifold Tee O-ring P/N" N/A V258BN V258VT V258ND
29 30 31 32 33   tem # 34 35 36 37 38 39 40 41 42 43 44    Mat   Neo   Ni   Fr   EF	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 2 2 4 32 1 1 1 1 1 terial prene itrile KM	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold (BSP) Suction Drop in Manifold (BSP) Elasto Versa-Rugged Diaphragm P/N V305N V305ND N/A	Wet End Assembly  Mer Material Specific  Versa-Dome  Diaphragm P/N  V306N  V306BN  V306VT  V306ND  N/A	P34 V3 V45  Part N V35 170.09 V36 V35 V35 V35 V351 V352 V25 V36 518.V00 518.V00 518.V00 64tions "Ball P/N" V455N V455N V455ND V455TF	N-501 D2E B6xx B5xx  wmber OFB D5.330 B7C B7B B8FB E-FB E-FB E-FB B2.156 D2.156 D3.156 D4.256N D5.256N	"Manifold Tee O-ring P/N" N/A V258BN V258VT V258ND V258TFS
29 30 31 32 33  Item # 34 35 36 37 38 39 40 41 42 43 44  Mat  Neo Ni FFI EFP Santo	12 2 4 4 4 <b>Qty.</b> 2 20 52 52 2 2 4 32 1 1 1 1 1 terial	Washer Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball (See Below Material Chart)  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow O-Ring Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold (BSP) Suction Drop in Manifold (BSP) Elasto Versa-Rugged Diaphragm P/N V305N V305N V305ND	Wet End Assembly  Mer Material Specific  Versa-Dome  Diaphragm P/N  V306N  V306BN  V306VT  V306ND	P34 V3 V45  Part N V35 170.09 V36 V35 V35 V35 V351 V352 V25 V36 518.V0 518.V0 518.V0 618.V0 618.V0 V36 V36 V37 V37 V37 V37 V37 V38	N-501 D2E B6xx B5xx  wmber OFB D5.330 B7C B7B B8FB E-FB E-FB B2.FB B2.156 D2.156 D3.156 D4.256 D5.256 D5.25	"Manifold Tee O-ring P/N" N/A V258BN V258VT V258ND

VERSAMATIC

# 3: EXP VIEW

# **Composite Repair Parts Drawing - PTFE Fitted**





# **Composite Repair Parts List - PTFE Fitted**

Itom #	Otre	Deparintion	Air Valve Assembly Part Nur	mbor
Item #	Qty.	Description Air Side Repair Kit (Includes Items		
		3,5,7,9,14,16,18-22)	476.029	.000
1	1	Valve Body (includes items 2-11)	031.V003	3.156
2	1	Valve Body	095.V00 <sup>2</sup>	1.156
3	1	Valve Body Gasket	P24-2	
4	1	Valve Sleeve	755.V00s	
5	6	O-ring	560.206	
6	1	Valve Spool Assembly (Includes items 7)	775.V001.000 P34.204E	
8	6	Glyde Ring Assembly Air Valve Screen	P34-204F P24-210	
9	2	End Cap Gasket	P24-2	
10	2	End Cap	P34-3	
11	13	Mounting Screws (8 included on item 1)	S100	
			enter Section Assembly	
Item #	Qty.	Description	Part Nur	
12	1	Center Block Assembly (Includes item 13 & 14)	P34-400D	
13	2	Bearing Sleeve	P34-4	
14	2	Main Shaft O-Ring	P34-4	
15 16	2	Air Chamber Air Chamber Gasket	196.V008 P79-1	
17	8	Bolt	P24-1	10
- ''		Pilot Repair Kit (Includes Items 18-22)	476.028	
18	1	Pilot Sleeve Assembly (include item 19)	755.V002	
19	6	O-ring	560.101	
20	1	Retaining Ring	675.037	.080
21	1	Pilot Spool Assembly (Includes item 22)	775.V006	
22	8	O-ring	560.023	
23	1	Muffler	530.033	.000
		·	ragm Assembly / Elastomers	mher
Item #	Qty.	Description	Part Nur	
	Qty.	Description	Part Nur PTFE Two Piece	PTFE Fusion
24 25		·	Part Nur	
24 25 26	1 2 2	<b>Description</b> Main Shaft  Diaphragm  Back-Up Diaphragm	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB	PTFE Fusion P34-103F
24 25 26 27	1 2 2 2	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO	<b>PTFE Fusion</b> P34-103F V305F
24 25 26 27 28	1 2 2 2 2	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI	PTFE Fusion P34-103F V305F N/A
24 25 26 27 28 29	1 2 2 2 2 2 2	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5	PTFE Fusion P34-103F V305F N/A
24 25 26 27 28 29 30	1 2 2 2 2 2 2 2	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E	PTFE Fusion P34-103F V305F N/A
24 25 26 27 28 29 30 31	1 2 2 2 2 2 2 2 2 4	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart)	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V456	PTFE Fusion P34-103F V305F N/A
24 25 26 27 28 29 30	1 2 2 2 2 2 2 2	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567	PTFE Fusion P34-103F V305F N/A
24 25 26 27 28 29 30 31 32	1 2 2 2 2 2 2 2 2 4 4	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4557 Wet End Assembly	PTFE Fusion P34-103F V305F N/A  01
24 25 26 27 28 29 30 31 32 <b>Item #</b>	1 2 2 2 2 2 2 2 4 4 4 Qty. 2	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart)	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F	PTFE Fusion P34-103F V305F N/A  01  xx FF  mber
24 25 26 27 28 29 30 31 32 <b>Item #</b> 33	1 2 2 2 2 2 2 4 4 4 Qty. 2 20	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Water Chamber	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055	PTFE Fusion P34-103F V305F N/A  01  xx FF mber FB .330
24 25 26 27 28 29 30 31 32 <b>Item #</b> 33 34	1 2 2 2 2 2 2 4 4 4 Qty. 2 20 52	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Bolt Nut	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055 V387	PTFE Fusion P34-103F V305F N/A  01  xx FF mber FB .330 C
24 25 26 27 28 29 30 31 32 <b>Item #</b> 33 34 35	1 2 2 2 2 2 2 4 4 4 <b>Qty.</b> 2 20 52 52	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Bolt Nut Washer	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055 V387	PTFE Fusion P34-103F V305F N/A  01  xx FF mber FB .330 C B
24 25 26 27 28 29 30 31 32 <b>Item #</b> 33 34 35 36 37	1 2 2 2 2 2 2 4 4 4 4 Qty. 2 20 52 52 2	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055 V387 V358F	PTFE Fusion P34-103F V305F N/A  01  xx FF mber FB .330 C B FB
24 25 26 27 28 29 30 31 32 Item # 33 34 35 36 37 38	1 2 2 2 2 2 2 4 4 4 4 Qty. 2 20 52 52 2 2	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055 V387 V358F V358F	PTFE Fusion P34-103F V305F N/A  01  xx FF mber FB .330 C B FB
24 25 26 27 28 29 30 31 32 <b>Item #</b> 33 34 35 36 37 38 39	1 2 2 2 2 2 2 4 4 4 4 Qty. 2 20 52 52 2 2 2 2	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055 V387 V358F V351E V352E	PTFE Fusion P34-103F V305F N/A  01  xx FF mber FB .330 C B FB -FB
24 25 26 27 28 29 30 31 32 Item # 33 34 35 36 37 38 39 40	1 2 2 2 2 2 4 4 4 Qty. 2 20 52 52 2 2 2 4 4	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow Manifold Seal	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI  P34-5 V302E  V4557 Wet End Assembly Part Nur V350F 170.055 V387 V387 V358F V351E V352E V258T	PTFE Fusion P34-103F V305F N/A  01  xx FF  mber FB .330 C B FB -FB -FB FS
24 25 26 27 28 29 30 31 32 <b>Item #</b> 33 34 35 36 37 38 39 40	1 2 2 2 2 2 2 4 4 4 4 Qty. 2 20 52 52 2 2 2 4 32 2	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow Manifold Seal Elbow Bolt	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055 V387 V358F V351E V358F	PTFE Fusion P34-103F V305F N/A  01  xx FF mber FB .330 C B FB -FB -FB FS D
24 25 26 27 28 29 30 31 32 Item # 33 34 35 36 37 38 39 40	1 2 2 2 2 2 4 4 4 Qty. 2 20 52 52 2 2 2 4 4	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow Manifold Seal Elbow Bolt Discharge Drop in Manifold	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055 V387 V358F V351E V358F	PTFE Fusion P34-103F V305F N/A  01  xxx FF  mber FB .330 C B FB FB FFB FS D 2.156
24 25 26 27 28 29 30 31 32 <b>Item #</b> 33 34 35 36 37 38 39 40 41	1 2 2 2 2 2 2 4 4 4 4 <b>Qty.</b> 2 20 52 52 2 2 2 4 32 1	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow Manifold Seal Elbow Bolt	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055 V387 V358F V351E V358F	PTFE Fusion P34-103F V305F N/A  01  xx FF mber FB .330 C B FB -FB -FB -FB -FB -FS D 2.156 .156 E
24 25 26 27 28 29 30 31 32 <b>Item #</b> 33 34 35 36 37 38 39 40	1 2 2 2 2 2 2 4 4 4 4 Qty. 2 20 52 52 2 2 2 4 32 2	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow Manifold Seal Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold (BSP)	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055 V387 V387 V351E V358F	PTFE Fusion P34-103F V305F N/A  01  xx FF mber FB .330 C B FB -FB -FB -FB -FB -FB -FS D 2.156 .156 .156 E 3.156
24 25 26 27 28 29 30 31 32 Item # 33 34 35 36 37 38 39 40 41 42	1 2 2 2 2 2 2 4 4 4 32 1 1	Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow Manifold Seal Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055 V387 V387 V358F V351E V358F	PTFE Fusion P34-103F V305F N/A  01  xx FF mber FB .330 C B FB -FB -FB -FB -FB -FS D 2.156 .156 E 3.156 .156 E
24 25 26 27 28 29 30 31 32 Item # 33 34 35 36 37 38 39 40 41 42 43	1 2 2 2 2 2 4 4 4 4 4 4 4 4 4 4 4 4 4 4	Description  Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow Manifold Seal Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold (BSP)  Suction Drop in Manifold (BSP)  Elast Seat P/N	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055 V387 V387 V351E V358F	PTFE Fusion P34-103F V305F N/A  01  xx FF mber FB .330 C B FB .FFB .FFB .FFB .FS D 2.156 .156 E 3.156 .156 E
24 25 26 27 28 29 30 31 32 Item # 33 34 35 36 37 38 39 40 41 42	1 2 2 2 2 2 2 4 4 4 4 4 4 4 4 4 4 4 4 4	Main Shaft Diaphragm Back-Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve Ball  Description Water Chamber Water Chamber Water Chamber Bolt Nut Washer Manifold Tee Discharge Elbow Suction Elbow Manifold Seal Elbow Bolt Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold	Part Nur PTFE Two Piece P34-103 V305TF-FB V305TFB V302TO V302TI P34-5 V302E V4567 Wet End Assembly Part Nur V350F 170.055 V387 V387 V358F V351E V358F	PTFE Fusion P34-103F V305F N/A  01  xxx FF  mber FB .330 C B FB -FB -FB -FB -FB -FB -FS D 2.156 .156 E 3.156 .156 E

## Notes:

(not pictured)

- 1.) The outer diaphragm plate material is to match the water chamber material (cast iron uses SV302B or SVB307)
- 2.) In addition to the stainless valve setas, (8) orings are needed. (4) SV456TES-1 and (4) SV456TES-2



# Material Codes - The Last 3 Digits of Part Number

- 000.....Assembly, sub-assembly; and some purchased items
- 010.....Cast Iron
- 015.....Ductile Iron
- 020.....Ferritic Malleable Iron
- 080.....Carbon Steel, AISI B-1112
- 110.....Alloy Type 316 Stainless Steel
- 111 .....Alloy Type 316 Stainless Steel (Electro Polished)
- 112.....Alloy C
- 113.....Alloy Type 316 Stainless Steel (Hand Polished)
- 114.....303 Stainless Steel
- 115.....302/304 Stainless Steel
- 117.....440-C Stainless Steel (Martensitic)
- 120.....416 Stainless Steel (Wrought Martensitic)
- 148..... Hardcoat Anodized Aluminum
- 150.....6061-T6 Aluminum
- 152.....2024-T4 Aluminum (2023-T351)
- 155.....356-T6 Aluminum
- 156.....356-T6 Aluminum
- 157.....Die Cast Aluminum Alloy #380
- 158.....Aluminum Alloy SR-319
- 162.....Brass, Yellow, Screw Machine Stock
- 165.....Cast Bronze, 85-5-5-5
- 166.....Bronze, SAE 660
- 170.....Bronze, Bearing Type, Oil Impregnated
- 180.....Copper Alloy
- 305.....Carbon Steel, Black Epoxy Coated
- 306.....Carbon Steel, Black PTFE Coated
- 307.....Aluminum, Black Epoxy Coated
- 308.....Stainless Steel, Black PTFE Coated
- 309.....Aluminum, Black PTFE Coated
- 313.....Aluminum, White Epoxy Coated
- 330.....Zinc Plated Steel
- 332.....Aluminum, Electroless Nickel Plated
- 333.....Carbon Steel, Electroless Nickel Plated
- 335.....Galvanized Steel
- 337.....Silver Plated Steel
- 351.....Food Grade Santoprene®
- 353.....Geolast; Color: Black
- 354.....Injection Molded #203-40
- Santoprene® Duro 40D +/-5;
  - Color: RED
- 356.....Hytrel®
- 357.....Injection Molded Polyurethane
- 358.....Urethane Rubber (Some Applications) (Compression Mold)
- 359..... Urethane Rubber
- 360.....Nitrile Rubber Color coded: RED
- 363.....FKM (Fluorocarbon)
  Color coded: YELLOW

- 364.....EPDM Rubber
  - Color coded: BLUE
- 365.....Neoprene Rubber Color coded: GREEN
- 366.....Food Grade Nitrile
- 368.....Food Grade EPDM
- 371.....Philthane (Tuftane)
- 374.....Carboxylated Nitrile
- 375.....Fluorinated Nitrile
- 378.....High Density Polypropylene
- 379.....Conductive Nitrile
- 408.....Cork and Neoprene
- 425.....Compressed Fibre
- 426.....Blue Gard
- 440.....Vegetable Fibre
- 500.....Delrin® 500
- 502.....Conductive Acetal, ESD-800
- 503.....Conductive Acetal, Glass-Filled
- 506.....Delrin® 150
- 520.....Injection Molded PVDF Natural color
- 540.....Nylon
- 542.....Nylon
- 544.....Nylon Injection Molded
- 550.....Polyethylene
- 551.....Glass Filled Polypropylene
- 552.....Unfilled Polypropylene
- 555.....Polyvinyl Chloride
- 556.....Black Vinyl
- 558.....Conductive HDPE
- 570.....Rulon II®
- 580.....Ryton®
- 600.....PTFE (virgin material)
  Tetrafluorocarbon (TFE)
- 603.....Blue Gylon®
- 604.....PTFE
- 606.....PTFE
- 607.....Envelon
- 608.....Conductive PTFE
- 610.....PTFE Encapsulated Silicon
- 611.....PTFE Encapsulated FKM
- 632.....Neoprene/Hytrel®
- 633.....FKM/PTFE
- 634.....EPDM/PTFE
- 635.....Neoprene/PTFE
- 637.....PTFE, FKM/PTFE
- 638.....PTFE, Hytrel®/PTFE
- 639.....Nitrile/TFE
- 643.....Santoprene®/EPDM
- 644.....Santoprene®/PTFE
- 656.....Santoprene® Diaphragm and Check Balls/EPDM Seats
- 661.....EPDM/Santoprene®
- 666.....FDA Nitrile Diaphragm,
  - PTFE Overlay, Balls, and Seals
- 668.....PTFE, FDA Santoprene®/PTFE

- Delrin and Hytrel are registered tradenames of E.I. DuPont.
- Nylatron is a registered tradename of Polymer Corp.
- Gylon is a registered tradename of Garlock. Inc.
- Santoprene is a registered tradename of Exxon Mobil Corp.
- Rulon II is a registered tradename of Dixion Industries Corp.
- Ryton is a registered tradename of Phillips Chemical Co.
- Valox is a registered tradename of General Electric Co.

# RECYCLING

Warren Rupp, manufacturer of Versamatic, is an ISO14001 registered company and is committed to minimizing the impact our products have on the environment. Many components of Versamatic® AODD pumps are made of recyclable materials. We encourage pump users to recycle worn out parts and pumps whenever possible, after any hazardous pumped fluids are thoroughly flushed. Pump users that recycle will gain the satisfaction to know that their discarded part(s) or pump will not end up in a landfill. The recyclability of Versamatic products is a vital part of Warren Rupp's commitment to environmental stewardship.



# 5 - YEAR Limited Product Warranty

#### Quality System ISO9001 Certified • Environmental Management Systems ISO14001 Certified

Versamatic warrants to the original end-use purchaser that no product sold by Versamatic that bears a Versamatic brand shall fail under normal use and service due to a defect in material or workmanship within five years from the date of shipment from Versamatic's factory.

The use of non-OEM replacement parts will void (or negate) agency certifications, including CE, ATEX, CSA, 3A and EC1935 compliance (Food Contact Materials). Warren Rupp, Inc. cannot ensure nor warrant non-OEM parts to meet the stringent requirements of the certifying agencies.

~ See complete warranty at http://vm.salesmrc.com/pdfs/VM\_Product\_Warranty.pdf

## DECLARATION OF CONFORMIT

DECLARATION DE CONFORMITE • DECLARACION DE CONFORMIDAD • ERKLÄRUNG BEZÜGLICH EINHALTUNG DER VORSCHRIFTEN DICHIARAZIONE DI CONFORMITÀ • CONFORMITEITSVERKLARING • DEKLARATION OM ÖVERENSSTÄMMELSE EF-OVERENSSTEMMELSESERKLÆRING • VAATIMUSTENMUKAISUUSVAKUUTUS • SAMSVARSERKLÄRING DECLARAÇÃO DE CONFORMIDADE

#### **MANUFACTURED BY:**

FABRIQUE PAR: FABRICADA POR: HERGESTELLT VON: FABBRICATO DA: VERVAARDIGD DOOR: TILLVERKAD AV: FABRIKANT: VALMISTAJA: PRODUSENT:

FABRICANTE:

#### VERSAMATIC ® Warren Rupp Inc.

A Unit of IDEX Corporation 800 North Main Street P.O. Box 1568 Mansfield, OH 44901-1568 USA

Tel: 419-526-7296 Fax: 419-526-7289



2006/42/EC

EN809:2012

to Annex VIII

on Machinery, according

## PUMP MODEL SERIES: E SERIES, V SERIES, VT SERIES, VSMA3, SPA15, **RE SERIES AND U2 SERIES**

#### This product complies with the following European Community Directives:

Ce produit est conforme aux directives de la Communauté européenne suivantes: Este producto cumple con las siguientes Directrices de la Comunidad Europea: Dieses produkt erfüllt die folgenden Vorschriften der Europäischen Gemeinschaft:

Questo prodotto è conforme alle seguenti direttive CEE:

Dir produkt voldoet aan de volgende EG-richtlijnen:

Denna produkt överensstämmer med följande EU direktiv:

Versamatic, Inc., erklærer herved som fabrikant, at ovennævnte produkt er i overensstemmelse med bestemmelserne i Direkktive:

Tämä tuote täyttää seuraavien EC Direktiivien vaatimukstet:

Dette produkt oppfyller kravene til følgende EC Direktiver:

Este produto está de acordo com as seguintes Directivas comunitárias:

#### This product has used the following harmonized standards to verify conformance:

Ce materiel est fabriqué selon les normes harmonisées suivantes, afin d' en garantir la conformité:

Este producto cumple con las siguientes directrices de la comunidad europa:

Dieses produkt ist nach folgenden harmonisierten standards gefertigtworden, die übereinstimmung wird bestätigt:

Questo prodotto ha utilizzato i seguenti standards per verificare la conformita':

De volgende geharmoniseerde normen werden gehanteerd om de conformiteit van dit produkt te garanderen:

För denna produkt har följande harmoniserande standarder använts för att bekräfta överensstämmelse:

Harmoniserede standarder, der er benyttet:

Tässä tuotteessa on sovellettu seuraavia yhdenmukaistettuja standardeja:

Dette produkt er produsert i overenstemmelse med fløgende harmoniserte standarder:

Este produto utilizou os seguintes padrões harmonizados para varificar conformidade:

## **AUTHORIZED/APPROVED BY:**

Approuve par: Aprobado por: Genehmigt von: approvato da: Goedgekeurd door: Underskrift: Valtuutettuna: Bemyndiget av: Autorizado Por:

Dave Roseberry Director of Engineering

Authorized Representative: **IDEX Pump Technologies** R79 Shannon Industrial Estate, Shannon, Co. Clare Ireland Attn: Barry McMahon

DATE: February 27, 2017

FECHA: DATUM: DATA: DATO: PÄIVÄYS:

VMQR 044FM

06/14/2017 REV 08

# **EU Declaration of Conformity**

## Manufacturer:

Versamatic A Unit of IDEX Corporation 800 North Main Street Mansfield, OH 44902 USA



Warren Rupp, Inc declares that Air Operated Double Diaphragm Pumps (AODD) and Surge Suppressors listed below comply with the requirements of **Directive 2014/34/EU** and all the applicable standards.

## **Applicable Standards:**

- EN ISO 80079-36: 2016
- EN ISO 80079-37: 2016
- EN60079-25: 2010
- 1. AODD Pumps and Surge Suppressors Technical File No.: 20310400 -1410/MER

**Hazardous Location Applied:** 

II 2 G Ex h IIC T5...225°C (T2) Gb II 2 D Ex h IIIC T100°C...T200°C Db

- Metal pump models with external aluminum components (E-series)
- Versa-Surge<sup>®</sup> surge suppressors (VTA-Series)
- 2. AODD Pumps Technical File No.: 20310400 -1410/MER On File With: DEKRA Certification B.V. (0344)

Meander 1051 6825 MJ Arnhem The Netherlands

Hazardous Location Applied:



I M2 Ex h Mb ⟨Ex⟩ II 2 G Ex h IIC T5...225°C (T2) Gb II 2 D Ex h IIIC T100°C...T200°C Db

- Metal pump models with no external aluminum (E-Series)
- Conductive plastic pumps (E-Series Plastic)
- See "Safety Information" page for conditions of safe use

DATE/OF REVISION/TITLE: 19 DEC 2018



Dave Roseberry Director of Engineering

